


HIKVISION



DS-K2600 Series Access Controller

User Manual



User Manual

©2017 Hangzhou Hikvision Digital Technology Co., Ltd.

This manual is applied for Ness Australian Version access controllers..

Product Name	Serials
Access Controller	DS-K2601 Serials Access Controller
	DS-K2602 Serials Access Controller
	DS-K2604 Serials Access Controller

It includes instructions on how to use the Product. The software embodied in the Product is governed by the user license agreement covering that Product.

About this Manual

This Manual is subject to domestic and international copyright protection. Hangzhou Hikvision Digital Technology Co., Ltd. (“Hikvision”) reserves all rights to this manual. This manual cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of Hikvision.

Modifications have been made to this manual by Ness Corporation Australia to suit the Australian market and to assist in Ness customers understanding the product easier.

Trademarks

HIKVISION and other Hikvision marks are the property of Hikvision and are registered trademarks or the subject of applications for the same by Hikvision and/or its affiliates. Other trademarks mentioned in this manual are the properties of their respective owners. No right of license is given to use such trademarks without express permission.

Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, REGARDING THIS MANUAL. HIKVISION DOES NOT WARRANT, GUARANTEE, OR MAKE ANY REPRESENTATIONS REGARDING THE USE OF THE MANUAL, OR THE CORRECTNESS, ACCURACY, OR RELIABILITY OF INFORMATION CONTAINED HEREIN. YOUR USE OF THIS MANUAL AND ANY RELIANCE ON THIS MANUAL SHALL BE WHOLLY AT YOUR OWN RISK AND RESPONSIBILITY.

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. OUR COMPANY SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, OUR COMPANY WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.

SURVEILLANCE LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS THE APPLICABLE LAW. OUR COMPANY SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW, THE LATER PREVAILS.

Support

Should you have any questions, please do not hesitate to contact your local dealer.

Regulatory Information

FCC Information

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC compliance: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Conditions

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

EU Conformity Statement



This product and – if applicable – the supplied accessories too are marked "CE" and comply therefore with the applicable harmonized European standards listed under the R&TTE Directive 1999/5/EC, the EMC Directive 2014/30/EU, the LVD Directive 2014/35/EU, the RoHS Directive 2011/65/EU.



2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclethis.info.



2006/66/EC (battery directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see: www.recyclethis.info.

Industry Canada ICES-003 Compliance

This device meets the CAN ICES-3 (A)/NMB-3(A) standards requirements.

Preventive and Cautionary Tips

Before connecting and operating your device, please be advised of the following tips:

- Ensure unit is installed in a well-ventilated, dust-free environment.
- Keep all liquids away from the device.
- Ensure environmental conditions meet factory specifications.
- Ensure unit is properly secured to a rack or shelf. Major shocks or jolts to the unit as a result of dropping it may cause damage to the sensitive electronics within the unit.
- Use the device in conjunction with an UPS if possible.
- Power down the unit before connecting and disconnecting accessories and peripherals.
- A factory recommended HDD should be used for this device.

Improper use or replacement of the battery may result in hazard of explosion. Replace with the same or equivalent type only. Dispose of used batteries according to the instructions provided by the manufacturer.



Safety Instruction



WARNING



Please note: There is high voltage (240VAC) inside the housing of the controller. Extreme caution should be taken and only installed and serviced by licensed trained installers.

These instructions are intended to ensure that user can use the product correctly to avoid danger or property loss.

The precaution measure is divided into **Warnings** and **Cautions**:

Warnings: Neglecting any of the warnings may cause serious injury or death.

Cautions: Neglecting any of the cautions may cause injury or equipment damage.

	
Warnings Follow these safeguards to prevent serious injury or death.	Cautions Follow these precautions to prevent potential injury or material damage.

Warnings

- All the electronic operation should be strictly compliance with the electrical safety regulations, fire prevention regulations and other related regulations in your local region.
- Please use the power adapter, which is provided by normal company. The power consumption cannot be less than the required value.
- Do not connect several devices to one power adapter as adapter overload may cause over-heat or fire hazard.
- **Please make sure that the power has been disconnected** before you wire, install or dismantle the device.
- When the product is installed on wall or ceiling, the device shall be firmly fixed.
- If smoke, odours or noise rise from the device, turn off the power at once and unplug the power cable, and then please contact the service centre.
- If the product does not work properly, please contact your dealer or the nearest service centre. Never attempt to disassemble the device yourself. (We shall not assume any responsibility for problems caused by unauthorized repair or maintenance.)



Cautions

- Do not drop the device or subject it to physical shock, and do not expose it to high electromagnetism radiation. Avoid the equipment installation on vibrations surface or places subject to shock (ignorance can cause equipment damage).
- Do not place the device in extremely hot (refer to the specification of the device for the detailed operating temperature), cold, dusty or damp locations, and do not expose it to high electromagnetic radiation. The appropriate operation temperature is 0°C to +45°C, and the storage temperature should be -10°C to +55°C.
- The device cover for indoor use shall be kept from rain and moisture.
- Exposing the equipment to direct sun light, low ventilation or heat source such as heater or radiator is forbidden (ignorance can cause fire danger).
- Do not aim the device at the sun or extra bright places. A blooming or smear may occur otherwise (which is not a malfunction however), and affecting the endurance of sensor at the same time.
- Please use the provided glove when open up the device cover, avoid direct contact with the device cover, because the acidic sweat of the fingers may erode the surface coating of the device cover.
- Please use a soft and dry cloth when clean inside and outside surfaces of the device cover, do not use alkaline detergents.
- Please keep all wrappers after unpack them for future use. In case of any failure occurred, you need to return the device to the factory with the original wrapper. Transportation without the original wrapper may result in damage on the device and lead to additional costs.
- Improper use or replacement of the battery may result in hazard of explosion. Replace with the same or equivalent type only. Dispose of used batteries according to the instructions provided by the battery manufacturer.
-

● Warning




Please note: There is high voltage (240VAC) inside the housing of the controller. Extreme caution should be taken and only installed and serviced by licensed trained installers.

Table of Contents

Chapter 1	Product Description	1
1.1	Overview	1
1.2	Main Features	1
Chapter 2	Component Description	3
Chapter 3	Terminal Connection	4
3.1	Terminal Description	4
3.1.1	DS-K2601 Terminal Description	4
3.1.2	DS-K2602 Terminal Description	6
3.1.3	DS-K2604 Terminal Description	9
Chapter 4	Card Reader Installation	13
4.1	External Terminal	13
4.1.1	DS-K2601 External Terminals	13
4.1.2	DS-K2602 External Terminals	13
4.1.3	DS-K2604 External Terminals	13
4.2	Card Reader Installation	14
4.2.1	The Connection of Wiegand Card Reader	14
4.2.2	RS485 Card Reader Connection	15
4.3	Installing E-Lock	16
4.3.1	Installation of Cathode Lock (Power to Unlock)	16
4.3.2	Installation of Anode Lock (Power to Lock)	16
4.4	Connecting the External Alarm Device	17
4.5	Door Button Wiring Diagram	17
4.6	The Connection of Magnetics Detection (Door Monitoring)	18
4.7	Connecting Power Supply	18
4.8	Arming Region Input Terminal	19
4.8.1	Connecting Normally Open Detector	19
4.8.2	Connecting Normally Closed Detector	19
4.9	Fire Alarm Module Wiring	20
Chapter 5	Settings	21
5.1	Initializing the Hardware	21
5.2	Relay Input NO/NC	21
5.2.1	Lock Relay Output	21
5.2.2	Alarm Relay Output Status	22
Chapter 6	Activating the Access Control Terminal	24

6.1	Activating via SADP Software	24
6.2	Activating via Client Software	25
Chapter 7	Client Operation	28
7.1	Function Module	28
7.2	User Registration and Login	31
7.3	System Configuration	33
7.4	Access Control Management	33
7.4.1	Adding Access Control Device	35
7.4.2	Viewing Device Status	39
7.4.3	Editing Basic Information	40
7.4.4	Network Settings	41
7.4.6	RS-485 Settings	41
7.4.7	Wiegand Settings	42
7.4.8	M1 Card Encryption	42
7.4.9	Remote Configuration	44
7.5	Person and Card Management	48
7.5.1	Organization Management	48
7.5.2	Person Management	50
7.6	Schedule and Template	64
7.6.1	Week Schedule	64
7.6.2	Holiday Group	67
7.6.3	Template	67
7.7	Permission Configuration	72
7.7.1	Adding Permission	73
7.7.2	Applying Permission	74
7.8	Advanced Functions	75
7.8.1	Access Control Parameters	75
7.8.1.1	Status Duration Configuration (Auto Unlock of Doors)	77
7.8.2	Card Reader Authentication	78
7.8.3	Multiple Authentication	84
7.8.4	Open Door with First Card	86
7.8.5	Anti-Passing Back	88
7.8.6	Cross-Controller Anti-passing Back	89
7.8.7	Multi-door Interlocking	92
7.8.8	Authentication Password	93
7.8.9	Custom Wiegand	94

7.9	Searching Access Control Event	97
7.10	Access Control Event Configuration	98
7.10.1	Access Control Event Linkage	99
7.10.2	Access Control Alarm Input Linkage.....	100
7.10.3	Event Card Linkage	102
7.10.4	Cross-Device Linkage.....	103
7.11	Door Status Management.....	105
7.11.1	Access Control Group Management	107
7.11.2	Anti-control the Access Control Point (Door).....	109
7.11.4	Real-time Card Swiping Record	115
7.11.5	Real-time Access Control Alarm.....	115
7.12	Arming Control.....	117
Appendix A Sound Prompt and Indicator		118
Appendix B Custom Wiegand Rule Descriptions.....		119



Chapter 1 Product Description

1.1 Overview

DS-K2600 is a powerful and stable access controller, using the logical architecture design. DS-K2600 is designed with TCP/IP network interface and its signal processed with special encryption and can be run offline. Anti-tampering function is also supported.

1.2 Main Features


- The access controller is equipped with 32-bit high-speed processor
- Supports TCP/IP network communication. The communication data is specially encrypted to relieve the concern of privacy leak
- Support recognition and storage of card number with maximum length of 20
- The access controller can store 100,000 legal cards (97,000 normal cards and 3,000 visitor cards) and 300,000 card swiping records
- Supports multi-door interlock function, anti-passback function, multi-card function, first card open function, super card and super password function, M1 card encryption, online upgrade function and remote control of the doors
- Supports tamper-proof alarm for card reader, alarm for door not secured, force opening door alarm, alarm for door opening timeout, duress card and code alarm, blacklist alarm and alarm for illegal card swiping attempts reaching the limit
- The alarm input of controller supports short circuit protection function and cut-proof function
- Multiple event upload methods: channel, center group, and listening
- 50 event and card linkages
- IP address conflict detection
- Cross-controller anti-passing back function (For cross-controller anti-passing back based on card, wire the card reader with RS-485. For cross-controller anti-passing back based on network, connect the server and device properly. Up to 5000 cards' swiping records can be stored in the selected server.) and inner-device anti-pass-back function
- Supports RS485 interface and Wiegand interface for accessing card reader. RS485 interface adopts dual-interface design and supports loop breakpoint detection and redundancy function; Wiegand interface supports W26, W34 and is seamlessly compatible with third-party card reader with Wiegand interface
- Supports various card types as normal/ disabled/ blacklist/ patrol/ guest/ duress/ super card, etc.
- Various indicators to show different status
- Supports time synchronization via NTP, manual or automatic method
- Supports record storage function when it is offline and insufficient storage space storage alarm function
- The access controller has backup battery design, watchdog design and tamper-proof function

- Data can be permanently saved after the access controller is powered off.
- Supports I/O linkage, and event linkage
- 500 groups of password under the authentication mode of card and password



Chapter 2 Component Description

Take DS-K2604 as an example, the component schematic diagram is shown below.




No.	Component Description		
	DS-K2601	DS-K2602	DS-K2604
1	Alarm Relay Output Status (NC/NO)		
2	Network Data Indicator		
3	RS-485 Communication Indicator		
4	Network Status Indicator		
5	Door Relay Output Status (NC/NO) Choice		
6	Battery Charging Indicator		
7	Power Indicator		
8	Charging Completing Indicator		
9	Running Indicator		
10	Hardware Initialization and Normal Working Choice		
11	Main board dial-up switch/ Reserved		

Chapter 3 Terminal Connection

3.1 Terminal Description

3.1.1 DS-K2601 Terminal Description




DS-K2601 Terminal descriptions are as follows:

No.	DS-K2601		
A1	Lock Power	GND	Grounding
A2		+12V	Power Output of the Lock
A3	Card Reader Power	GND	Grounding
A4		+12V	Power Output of the Head Read
A5	Wiegand Card Reader 2	GND	Grounding
A6		W0	Wiegand Head Read Data Input Data0
A7		W1	Wiegand Head Read Data Input Data1
A8		BZ	Card Reader Buzzer Control Output

No.	DS-K2601		
A9		ERR	Indicator of Card Reader Control Output (Invalid Card Output)
A10		OK	Indicator of Card Reader Control Output (Valid Card Output)
A11	Wiegand Card Reader 1	GND	Grounding
A12		W0	Wiegand Head Read Data Input Data0
A13		W1	Wiegand Head Read Data Input Data1
A14		BZ	Card Reader Buzzer Control Output
A15		ERR	Indicator of Card Reader Control Output (Invalid Card Output)
A16		OK	Indicator of Card Reader Control Output (Valid Card Output)
B1	Arming Region Input	Z1	Arming Region Access Terminal 1 (Only for Linkage of Alarm Relay Output)
B2		GND	Grounding
B3		Z2	Arming Region Access Terminal 2 (Only for Linkage of Alarm Relay Output)
B4		Z3	Arming Region Access Terminal 3 (Only for Linkage of Alarm Relay Output)
B5		GND	Grounding
B6		Z4	Arming Region Access Terminal 4 (Only for Linkage of Alarm Relay Output)
B7	E-Lock	D1+	Door 1 Door Relay Input (Dry Contact)
B8		D1-	
B9	Door Contact Input	S1	Door 1 Door Contact Detector Input
B10		GND	Grounding
B11	Door Open Button	B1	Door 1 Door Open Button Input
B12		GND	Grounding
C1	Power	+12V	DC12V Cathode
C2		GND	DC12V Grounding Input
C3	Battery	BAT+	DC12V Battery Cathode
C4		BAT-	DC12V Battery Anode
C5	485 Card Reader	RS 485A+	Card Reader RS485+ Access
C6		RS 485A-	Card Reader RS485- Access
C7		GND	Grounding
C8		RS 485B+	Card Reader RS485+
C9		RS 485B-	Card Reader RS485-
C10		GND	Grounding
C11	Access Controller RS485 Interface	RS 485C+	Uplink RS485+Communication
C12		RS 485C-	Uplink RS485-Communication
C13		GND	Grounding

No.	DS-K2601		
C14		RS 485D+	Reserved
C15		RS 485D-	
C16		GND	
C17	Alarm Output	NO/NC1	Alarm Relay 1 Output (Dry Contact)
C18		COM1	
C19	Alarm Output	NO/NC2	Alarm Relay 2 Output (Dry Contact)
C20		COM2	
D1	Event Input	C2	Event Alarm Input 2
D2		GND	Grounding
D3		C1	Event Alarm Input 1

3.1.2 DS-K2602 Terminal Description




DS-K2602 Terminal descriptions are as follows:

No.	DS-K2602		
A1	Power for E-Lock	GND	Grounding
A2		+12V	Power Output of the Lock

No.	DS-K2602		
A3	Power for Card Reader	GND	Grounding
A4		+12V	Power Output of the Head Read
A5	Wiegand Card Reader 4	GND	Grounding
A6		W0	Wiegand Head Read Data Input Data0
A7		W1	Wiegand Head Read Data Input Data1
A8		BZ	Card Reader Buzzer Control Output
A9		ERR	Indicator of Card Reader Control Output (Invalid Card Output)
A10		OK	Indicator of Card Reader Control Output (Valid Card Output)
A11	Wiegand Card Reader 3	GND	Grounding
A12		W0	Wiegand Head Read Data Input Data0
A13		W1	Wiegand Head Read Data Input Data1
A14		BZ	Card Reader Buzzer Control Output
A15		ERR	Indicator of Card Reader Control Output (Invalid Card Output)
A16		OK	Indicator of Card Reader Control Output (Valid Card Output)
A17	Wiegand Card Reader 2	GND	Grounding
A18		W0	Wiegand Head Read Data Input Data0
A19		W1	Wiegand Head Read Data Input Data1
A20		BZ	Card Reader Buzzer Control Output
A21		ERR	Indicator of Card Reader Control Output (Invalid Card Output)
A22		OK	Indicator of Card Reader Control Output (Valid Card Output)
A23	Wiegand Card Reader 1	GND	Grounding
A24		W0	Wiegand Head Read Data Input Data0
A25		W1	Wiegand Head Read Data Input Data1
A26		BZ	Card Reader Buzzer Control Output
A27		ERR	Indicator of Card Reader Control Output (Invalid Card Output)
A28		OK	Indicator of Card Reader Control Output (Valid Card Output)
B1	Arming Region	Z1	Arming Region Access Terminal 1 (Only for Linkage of Alarm Relay Output)
B2		GND	Grounding
B3		Z2	Arming Region Access Terminal 2 (Only for Linkage of Alarm Relay Output)
B4		Z3	Arming Region Access Terminal 3 (Only for Linkage of Alarm Relay Output)
B5		GND	Grounding
B6		Z4	Arming Region Access Terminal 4 (Only for Linkage of Alarm Relay Output)
B7		E-Lock1	D1+

No.	DS-K2602		
B8		D1-	
B9	E-Lock2	D2+	Door 2 Door Relay Input (Dry Contact)
B10		D2-	
B11	Door Magnetics Detector	S1	Door 1 Magnetic Detector Input
B12		GND	Signal Grounding
B13		S2	Door 2 Magnetic Detector Input
B14	Door Button	B1	Door 1 Door Button Input
B15		GND	Signal Grounding
B16		B2	Door 2 Door Button Input
C1	Power	+12V	DC12V Cathode
C2		GND	Grounding
C3	Battery	BAT+	DC12V Battery Cathode
C4		BAT-	DC12V Battery Anode
C5	Card Reader 485 Interface	RS 485A+	Card Reader RS485+ Access
C6		RS 485A-	Card Reader RS485- Access
C7		GND	Grounding
C8		RS 485B+	Card Reader RS485+
C9		RS 485B-	Card Reader RS485-
C10		GND	Grounding
C11	RS-485 Interface	RS 485C+	Uplink RS485+Communication
C12		RS 485C-	Uplink RS485-Communication
C13		GND	Grounding
C14		RS 485D+	Reserved
C15		RS 485D-	
C16		GND	
C17	Alarm Output	NO/NC1	Alarm Relay 1 Output (Dry Contact)
C18		COM1	
C19		NO/NC2	Alarm Relay 2 Output (Dry Contact)
C20		COM2	
C21		NO/NC3	Alarm Relay 3 Output (Dry Contact)
C22		COM3	
C23		NO/NC4	Alarm Relay 4 Output (Dry Contact)
C24		COM4	
D1	Event Input	C4	Event Alarm Input 4
D2		GND	Grounding
D3		C3	Event Alarm Input3
D4		C2	Event Alarm Input 2
D5		GND	Grounding
D6		C1	Event Alarm Input 1

3.1.3 DS-K2604 Terminal Description



DS-K2604 Terminal descriptions are as follows:

No.	DS-K2604		
A1	Power Supply of E-Lock	GND	Grounding
A2		+12V	Power Supply of E-Lock Output
A3	Power Supply of Card Reader	GND	Grounding
A4		+12V	Power Supply of Card Reader Output
A5	Wiegand Card Reader 4	GND	Grounding
A6		W0	Wiegand Card Reader Data Input Data0
A7		W1	Wiegand Card Reader Data Input Data1
A8		BZ	Buzzer of Card Reader Control Output
A9		ERR	Creset of Card Reader Control Output (Invalid Card Output)
A10		OK	Creset of Card Reader Control Output (Valid Card Output)
A11	Wiegand Card Reader 3	GND	Grounding
A12		W0	Wiegand Card Reader Data Input Data0
A13		W1	Wiegand Card Reader Data Input Data1
A14		BZ	Buzzer of Card Reader Control Output

No.	DS-K2604		
A15		ERR	Cresset of Card Reader Control Output (Invalid Card Output)
A16		OK	Cresset of Card Reader Control Output (Valid Card Output)
A17	Wiegand Card Reader 2	GND	Grounding
A18		W0	Wiegand Card Reader Data Input Data0
A19		W1	Wiegand Card Reader Data Input Data1
A20		BZ	Buzzer of Card Reader Control Output
A21		ERR	Cresset of Card Reader Control Output (Invalid Card Output)
A22		OK	Cresset of Card Reader Control Output (Valid Card Output)
A23	Wiegand Card Reader 1	GND	Grounding
A24		W0	Wiegand Card Reader Data Input Data0
A25		W1	Wiegand Card Reader Data Input Data1
A26		BZ	Buzzer of Card Reader Control Output
A27		ERR	Cresset of Card Reader Control Output (Invalid Card Output)
A28		OK	Cresset of Card Reader Control Output (Valid Card Output)
B1	Arming Region Input	Z1	Arming Region Access Terminal 1 (Only for Linkage of Alarm Relay Output)
B2		GND	Grounding
B3		Z2	Arming Region Access Terminal 2 (Only for Linkage of Alarm Relay Output)
B4		Z3	Arming Region Access Terminal 3 (Only for Linkage of Alarm Relay Output)
B5		GND	Grounding
B6		Z4	Arming Region Access Terminal 4 (Only for Linkage of Alarm Relay Output)
B7	E-Lock 1	D1+	Door 1 Door Relay Input (Dry Contact)
B8		D1-	
B9	E-Lock 2	D2+	Door 2 Door Relay Input (Dry Contact)
B10		D2-	
B11	E-Lock 3	D3+	Door 3 Door Relay Input (Dry Contact)
B12		D3-	
B13	E-Lock 4	D4+	Door 4 Door Relay Input (Dry Contact)
B14		D4-	
B15	Door Magnetics Input	S1	Door 1 Magnetic Detector Input
B16		GND	Signal Grounding
B17		S2	Door 2 Magnetic Detector Input
B18		S3	Door 3 Magnetic Detector Input
B19		GND	Signal Grounding
B20		S4	Door 4 Magnetic Detector Input

No.	DS-K2604		
B21	Door Button	B1	Door 1 Door Button Input
B22		GND	Signal Grounding
B23		B2	Door 2 Door Button Input
B24		B3	Door 3 Door Button Input
B25		GND	Signal Grounding
B26		B4	Door 4 Door Button Input
C1	Power	+12V	DC12V Cathode
C2		GND	Grounding
C3	Battery	BAT+	DC12V Battery Cathode
C4		BAT-	DC12V Battery Anode
C5	Card Reader RS485	RS 485A+	Card Reader RS485A+
C6		RS 485A-	Card Reader RS485A-
C7		GND	Grounding
C8		RS 485B+	Card Reader RS485B+
C9		RS 485B-	Card Reader RS485B-
C10		GND	Grounding
C11	Access Controller RS485	RS 485C+	Uplink RS485+Communication
C12		RS 485C-	Uplink RS485-Communication
C13		GND	Grounding
C14		RS 485D+	Reserved
C15		RS 485D-	
C16		GND	
C17	Alarm Output	NO/NC1	Alarm Relay 1 Output (Dry Contact)
C18		COM1	
C19		NO/NC2	Alarm Relay 2 Output (Dry Contact)
C20		COM2	
C21		NO/NC3	Alarm Relay 3 Output (Dry Contact)
C22		COM3	
C23		NO/NC4	Alarm Relay 4 Output (Dry Contact)
C24		COM4	
D1	Event Input	C8	Event Alarm Input 8
D2		GND	Grounding
D3		C7	Event Alarm Input 7
D4		C6	Event Alarm Input 6
D5		GND	Grounding
D6		C5	Event Alarm Input 5
D7		C4	Event Alarm Input 4
D8		GND	Grounding
D9		C3	Event Alarm Input3
D10		C2	Event Alarm Input 2
D11		GND	Grounding
D12		C1	Event Alarm Input 1

Notes:


- The Alarm input hardware interface is normally open by default. So only the normally open signal is allowed. It can be linked to the buzzer of the card reader and access controller, and the alarm relay output and open door relay output.
- Arming region alarm input is only for the alarm relay output linkage.
- RS485 card ID should be set as 1 to 8. For example, the ID of door 1 is 1 and 2 standing for in and out respectively.
- For single-door access controller, the Wiegand card reader 1 and 2 respectively correspond to the entering and exiting card readers of door 1. For two-door access controller, the Wiegand card reader 1 and 2 respectively correspond to the entering and exiting card readers of door 1, and the Wiegand card reader 3 and 4 respectively correspond to the entering and exiting card readers of door 2. For single-door access controller, the Wiegand card reader 1, 2, 3 and 4 respectively correspond to the entering card readers of door 1, 2, 3, and 4.




Chapter 4 Card Reader Installation

4.1 External Terminal


4.1.1 DS-K2601 External Terminals



4.1.2 DS-K2602 External Terminals




4.1.3 DS-K2604 External Terminals



CORPORATION


4.2 Card Reader Installation

4.2.1 The Connection of Wiegand Card Reader



Note: Optionally you must connect the OK/ERR/BZ, if using access controller to control the LED and buzzer of the Wiegand card reader.


4.2.2 RS485 Card Reader Connection




Note: If the card reader is installed too far away from the access controller, you can use an external power supply.

4.3 Installing E-Lock


4.3.1 Installation of Cathode Lock (*Power to Unlock / Fail Secure*)




4.3.2 Installation of Anode Lock (*Power to lock / Fail Safe*)




4.4 Connecting the External Alarm Device




4.5 Door Button Wiring Diagram



4.6 The Connection of Door Monitoring Reed Switches (Magnetics Detection)




4.7 Connecting Power Supply




4.8 Arming Region Input Terminal


4.8.1 Connecting Normally Open Detector



4.8.2 Connecting Normally Closed Detector



4.9 Fire Alarm Module Wiring



Chapter 5 Settings

5.1 Initializing the Hardware

Option 1:

Steps:

1. Remove the jumper cap from the Normal terminal.
2. Disconnect the power and restart the access controller. The controller buzzer buzzes a long beep.
3. When the beeping stops (~10-60 seconds), plug the jumper cap back to Normal.

Option 2:

Steps:

1. Jump the jumper cap from Normal to Initial.
2. Disconnect the power and restart the access controller. The controller buzzer buzzes a long beep.
3. When the beeping stops (~10-60 seconds), plug the jumper cap back to Normal.





Figure 1-1 Initialization Dial-up

Note: The initializing of the hardware will restore all the parameters to the default setting and all the device events are wiping out.


5.2 Relay Input NO/NC

5.2.1 Lock Relay Output

Lock Relay Normally Open Status:




Lock Relay Normally Closed Status:




5.2.2 Alarm Relay Output Status

Alarm Relay Output Normally Open:




Alarm Relay Output Normally Closed:



Work Flow of Software

For detailed information, please see the user manual of the client software.
Refer to the following work flow:



Chapter 6 Activating the Access Control Terminal

Purpose:

You are required to activate the terminal first before using it. Activation via SADP, and Activation via client software are supported. The default values of the control terminal are as follows.

- The default IP address: 192.0.0.64.
- The default port No.: 8000.
- The default user name: admin.


6.1 Activating via SADP Software

SADP software is used for detecting the online device, activating the device, and resetting the password.

Get the SADP software from the supplied disk or the official website, and install the SADP according to the prompts. Follow the steps to activate the control panel.

Steps:

1. Run the SADP software to search the online devices.
2. Check the device status from the device list, and select an inactive device.



3. Create a password and input the password in the password field, and confirm the password.



STRONG PASSWORD RECOMMENDED— We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

4. Click **Activate** to activate the device.
5. Check the activated device. You can change the device IP address to the same network segment with your computer by either modifying the IP address manually or checking the checkbox of Enable DHCP.

Modify Network Parameters

Enable DHCP

Device Serial No.:

IP Address:

Port:

Subnet Mask:

Gateway:

IPv6 Address:

IPv6 Gateway:

IPv6 Prefix Length:

HTTP Port:

Security Verification

Admin Password:

Modify [Forgot Password](#)


6. Input the password and click the **Modify** button to activate your IP address modification.

6.2 Activating via Client Software

The client software is versatile video management software for multiple kinds of devices. Get the client software from the supplied disk or the official website, and install the software according to the prompts. Follow the steps to activate the control panel.

Steps:

1. Run the client software and the control panel of the software pops up, as shown in the figure below.



2. Click the **Device Management** to enter the Device Management interface.
3. Check the device status from the device list, and select an inactive device.

IP	Device Type	Firmware Version	Security	Server Port	Device Serial No.	Start Time
192.0.0.64			Active	8000		2017-01
192.168.1.64			Inactive	8000		2017-01

4. Click the **Activate** button to pop up the Activation interface.
5. In the pop-up window, create a password in the password field, and confirm the password.



STRONG PASSWORD RECOMMENDED– We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

6. Click **OK** button to start activation.
7. Click the **Modify Netinfor** button to pop up the Network Parameter Modification interface.
8. Change the device IP address to the same network segment with your computer by either modifying the IP address manually.
9. Input the password and click the **OK** button to save the settings.




Chapter 7 Client Operation

You can set and operate the access control devices via the client software. This chapter will introduce the access control device related operations in the client software. For integrated operations, refer to *User Manual of iVMS-4200 Client Software*.

7.1 Function Module

Control Panel of iVMS-4200:



Menu Bar:

File	Open Image File	Search and view the captured pictures stored on local PC.
	Open Video File	Search and view the video files recorded on local PC.
	Open Log File	View the backup log files.
	Exit	Exit the iVMS-4200 client software.
System	Lock	Lock screen operations. Log in the client again to unlock.
	Switch User	Switch the login user.
	Import System Config File	Import client configuration file from your computer.
	Export System Config File	Export client configuration file to your computer.
	Auto Backup	Set the schedule for backing up the database including person, attendance data, and permission data automatically.
View	1024*768	Display the window at size of 1024*768 pixels.

	1280*1024	Display the window at size of 1280*1024 pixels.	
	1440*900	Display the window at size of 1440*900 pixels.	
	1680*1050	Display the window at size of 1680*1050 pixels.	
	Maximize	Display the window in maximum mode.	
	Control Panel	Enter Control Panel interface.	
	Main View	Open Main View page.	
	Remote Playback	Open Remote Playback page.	
	Access Control	Enter the Access Control Module.	
	Status Monitor	Enter the Status Monitor Module.	
	Time and Attendance	Enter the Time and Attendance Module.	
	Security Control Panel	Enter the Security Control Panel Module.	
	Real-time Alarm	Enter the Real-time Alarm Module.	
	Video Wall	Open Video Wall page.	
	E-map	Open E-map page.	
	Auxiliary Screen Preview	Open Auxiliary Screen Preview window.	
	Tool	Device Management	Open the Device Management page.
		Event Management	Open the Event Management page.
		Storage Schedule	Open the Storage Schedule page.
Account Management		Open the Account Management page.	
Log Search		Open the Log Search page.	
System Configuration		Open the System Configuration page.	
Broadcast		Select camera to start broadcasting.	
Device Arming Control		Set the arming status of devices.	
Alarm Output Control		Turn on/off the alarm output.	
Batch Wiper Control		Batch starting or stopping the wipers of the devices.	
Batch Time Sync		Batch time synchronization of the devices.	
Player		Open the player to play the video files.	
Message Queue		Display the information of Email message to be sent.	
Help	Open Video Wizard	Open the video guide for the video surveillance configuration.	
	Open Video Wall Wizard	Open the guide for the video wall configuration.	
	Open Security Control Panel Wizard	Open the guide for the security control panel configuration.	
	Open Access Control and Video Intercom Wizard	Open the guide for the access control and video intercom configuration.	
	Open Attendance Wizard	Open the guide for the time and attendance configuration.	
	User Manual (F1)	Click to open the User Manual; you can also open the User Manual by pressing F1 on your keyboard.	
	About	View the basic information of the client software.	
	Language	Select the language for the client software and reboot the software to activate the settings.	


For the first time running the software, you can click




on the control

panel to select the modules to display on the Operation and Control area of the control pane.

Steps:

1. Click  to pop up the following dialog.



















2. Check the module checkboxes to display them on the control panel according to the actual needs.
3. Click **OK** to save the settings.

Notes:

- After adding the access control device in Device Management module, the Access Control, Status, and Time and Attendance module will be displayed on the control panel automatically.
- After adding the security control panel in Device Management module, the Security Control Panel and Real-time Alarm modules will be displayed on the control panel automatically.

The iVMS-4200 client software is composed of the following function modules:

	The Main View module provides live view of network cameras and video encoders, and supports some basic operations, such as picture capturing, recording, PTZ control, etc.
	The Remote Playback module provides the search, playback, export of video files.
	The Access Control module provides managing the organizations, persons, permissions, and advanced access control functions. Provides video intercom function.
	The Status Monitor module provides monitoring and controlling the door status, viewing the real-time card swiping records and access control events.
	The Time and Attendance module provides setting the attendance rule for the employees and generating the reports.
	The Security Control Panel module provides operations such as arming, disarming, bypass, group bypass, and so on for both the partitions and zones.

	The Real-time Alarm module provides displaying the real-time alarm of security control panel, acknowledging alarms, and searching the history alarms.
	The Alarm Event module displays the alarm and event received by the client software.
	The Video Wall module provides the management of decoding device and video wall and the function of displaying the decoded video on video wall.
	The E-map module provides the displaying and management of E-maps, alarm inputs, hot regions and hot spots.
	The Device Management module provides the adding, modifying and deleting of different devices and the devices can be imported into groups for management.
	The Event Management module provides the settings of arming schedule, alarm linkage actions and other parameters for different events.
	The Storage Schedule module provides the schedule settings for recording and pictures.
	The Account Management module provides the adding, modifying and deleting of user accounts and different permissions can be assigned for different users.
	The Log Search module provides the query of system log files and the log files can be filtered by different types.
	The System Configuration module provides the configuration of general parameters, file saving paths, alarm sounds and other system settings.

The function modules are easily accessed by clicking the navigation buttons on the control panel or by selecting the function module from the **View** or **Tool** menu.


You can check the information, including current user, network usage, CPU usage, memory usage and time, in the upper-right corner of the main page.

7.2 User Registration and Login

For the first time to use iVMS-4200 client software, you need to register a super user for login.

Steps:

1. Input the super user name and password. The software will judge password strength automatically, and we highly recommend you to use a strong password to ensure your data security.
2. Confirm the password.
3. Optionally, check the checkbox **Enable Auto-login** to log into the software automatically.
4. Click **Register**. Then, you can log into the software as the super user.



- ◆ A user name cannot contain any of the following characters: / \ : * ? " < > |. And the length of the password cannot be less than 6 characters.
- ◆ For your privacy, we strongly recommend changing the password to something of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product.
- ◆ Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.


When opening iVMS-4200 after registration, you can log into the client software with the registered user name and password.

Steps:

1. Input the user name and password you registered.

Note: If you forget your password, please click **Forgot Password** and remember the encrypted string in the pop-up window. Contact your dealer and send the encrypted string to him to reset your password.

2. Optionally, check the checkbox **Enable Auto-login** to log into the software automatically.
3. Click **Login**.



After running the client software, you can open the wizards (including video wizard, video wall wizard, security control panel wizard, access control and video intercom wizard, and attendance wizard), to guide you to add the device and do other settings and operations. For detailed configuration about the wizards, please refer to the *Quick Start Guide of iVMS-4200*.


7.3 System Configuration

Purpose:

You can synchronize the missed access control events to the client.

Steps:

1. Click **Tool – System Configuration**.
2. In the System Configuration window, check the **Auto-synchronize Access Control Event** checkbox.
3. Set the synchronization time.
The client will auto-synchronize the missed access control event to the client at the set time.



7.4 Access Control Management

Purpose:

The Access Control module is applicable to access control devices and video intercom. It provides multiple functionalities, including person and card management, permission configuration, access control status management, video intercom, and other advanced functions.


You can also set the event configuration for access control and display access control points and zones on E-map.


Note: For the user with access control module permissions, the user can enter the Access Control module and configure the access control settings.



Click  in the control panel, and check **Access Control** to add the Access Control module to the control panel.




Click  to enter the Access Control module.



Before you start:

For the first time opening the Access Control module, the following dialog will pop up and you are required to select the scene according to the actual needs.








You can select the scene as **Non-residence** and **Residence**.



Notes:

- Once the scene is configured, you cannot change it later.
- When you select **Residence** mode, you cannot configure the Attendance Rule when adding person.


The Access Control module is composed of the following sub modules.

	Person and Card	Managing the organizations, persons, and assigning cards to persons.
	Schedule and Template	Configuring the week schedule, holiday group, and setting the template.
	Permission	Assigning access control permissions to persons and applying to the devices.
	Advanced Function	Providing advanced functions including access control parameters settings, card reader authentication, opening door with first card, anti-passing back, multi-door interlocking, and authentication password.
	Video Intercom	Video intercom between client and resident, searching the dial log, and releasing notice.
	Search	Searching history events of access control; Searching call logs, unlocking logs, and released notices.
	Device Management	Managing the access control devices and video intercom devices.

Note: In this chapter, we only introduce the operations about access control.


7.4.1 Adding Access Control Device


From within the 'Access Control' module, Click  in the Access Control module to enter the following interface.



Purpose:

The active online devices in the same local subnet will be displayed in the in the **Online Device** area (i.e. bottom section of 'Device management') within the iVMS4200 software. This area is Refreshed every 60 seconds.



Note: You can click  to hide the **Online Device** area.

Steps for adding a device to your iVMS4200 Client Software:

Note: Before a device can be added to the software it need to be activated [Refer Chapter 6 - Activating the Access Control Terminal](#) (Page 24)

1. Select the devices to be added from the list (ie. From Online Device List at the bottom window of the screen.).

IP	Device Type	Firmware Version	Security	Server Port	Device Serial No.	Start Time	Added
192.168.0.192	DS-K2804	V1.0.1build 160302	Active	8000	DS-K280420160...	2018-02-27 16:06:33	No
192.168.0.193	DS-K2604	V2.0.2build 171107	Active	8000	DS-K260420171...	2018-02-27 16:06:33	Yes
192.168.0.197	DS-K2210	V1.0.0build 161130	Active	8000	DS-K221020161...	2018-02-27 16:06:33	Yes

2. Click **Add to Client** to open the device adding dialog box.

3. Input the required information.

Add

Adding Mode:

IP/Domain IP Segment Hik-Connect D... EHome Serial Port

IP Server HIDDNS Batch Import

Add Offline Device

Nickname: **A. Give the controller a name.**

Address:

Port:

User Name: **B. Enter the Username and password (password used to activate the controller)**

Password:

Export to Group
Set the device name as the group name and add all the channels connected to the device to the group.

 C. Click Add.

Nickname: Edit a name for the device as you want to use for this controller. (Maybe location so it can easily be identified at a later date)

Address: Input the device’s IP address. The IP address of the device is obtained automatically in this adding mode.


Port: Input the device port No. The default value is 8000.

User Name: Input the device user name. By default, the user name is *admin*.

Password: Input the device password. (password used to activate the controller)



The password strength of the device can be checked by the software. For your privacy, we strongly recommend changing the password to something of your own choosing (using a minimum of 8 characters, including upper and lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.



4. Optionally, check the **Export to Group** checkbox to create a group by the device name. You can import all the channels of the device to the corresponding group by default.

➤ **Adding Multiple Online Device**


If you want to add multiple online devices to the client software, click and hold *Ctrl* key to select multiple devices, and click **Add to Client** to open the device adding dialog box. In the pop-up message box, enter the user name and password for the devices to be added.

➤ **Adding All Online Devices**

If you want to add all the online devices to the client software, click **Add All** and click **OK** in the pop-up message box. Then enter the user name and password for the devices to be added.

Note: After adding the device, you should check the device arming status in **Tool – Device Arming Control**. If the device is not armed, (i.e. Armed to receive events) you should arm it, or you will not receive the real-time events into the iVMS4200 client software. For details about device arming control, refer 7.11 *Arming Control*.



Note: After adding the device, you should check the device arming status in **Tool – Device Arming Control**. If the device is not armed, you should arm it, or you will not receive the real-time events via the client software. For details about device arming control, refer *7.11 Arming Control*.



Note: After adding the device, you should check the device arming status in **Tool – Device Arming Control**. If the device is not armed, you should arm it, or you will not receive the real-time events via the client software. For details about device arming control, refer *7.11 Arming Control*.

7.4.2 Viewing Device Status

In the device list, you can select the device and then click **Device Status** button to view its status.



RATION

Note: The interface may different from the picture displayed above. Refer to the actual interface when adopting this function.

Door Status: The status of the connected door.

Host Status: The status of the host, including Storage Battery Power Voltage, Device Power Supply Status, Multi-door Interlocking Status, Anti-passing Back Status, Host Anti-Tamper Status and number of cards added to the controller.

Card Reader Status: The status of card reader.

Note: If you use the card reader with RS-485 connection, you can view the status of online or offline. If you use the card reader with Wiegand connection, the status will always be shown as 'offline'.

Alarm Input Status: The alarm input status of each port.

Alarm Output Status: The alarm output status of each port.

Event Sensor Status: The event sensor status of each port.

Secure Door Control Unit Status: The online status and tamper status of the Secure Door Control Unit.

Arming Status: The status of the device.

7.4.3 Editing Basic Information

Purpose:

After adding the access control device, you can edit the device basic information.

Steps:

1. Select the device in the device list.
2. Click **Modify** to pop up the modifying device information window.
3. Click **Basic Information** tab to enter the Basic Information interface.

4. Edit the device information, including the adding mode, the device name, the device IP address, port No., user name, and the password.

7.4.4 Network Settings

Purpose:

After adding the access control device, you can set the uploading mode, and set the network center and wireless communication center.

It is recommended to leave these settings as default.

7.4.5 RS-485 Settings

Purpose:

You can set the RS-485 parameters including the serial port, the baud rate, the data bit, the stop bit, the parity type, the communication mode, and the working mode. Select the device in the device list, and click **Modify** to pop up the modifying device information window.

It is recommended to leave these settings as default unless instructed to change by Ness Technical staff.

Click **RS-485 Settings** tab to enter the RS-485 settings interface.

Note: The RS-485 Settings should be supported by the device.

Steps:

1. Click **RS-485 Settings** tab to enter the RS-485 settings interface.

The screenshot shows a configuration window for RS-485 settings. It contains the following fields and options:

- Serial Port: 1
- Baud Rate: 19200
- Data Bit: 8Bit
- Stop Bit: 1Bit
- Parity: None
- Communication Mode: Half Duplex
- Working Mode: Console
- Save button

It is recommended to leave these settings as default unless instructed to change by Ness Technical staff.

2. Select the serial No. of the port from the dropdown list to set the RS-485 parameters.
3. Set the baud rate, data bit, the stop bit, parity type, communication mode, and work mode in the dropdown list.
4. Click **Save** to save the settings and the configured parameters will be applied to the device automatically.

Note: After changing the working mode, the device will be rebooted. A prompt will be popped up after changing the working mode.

7.4.6 Wiegand Settings

Purpose:

You can set the Wiegand channel and the communication mode.

Select the device in the device list, and click **Modify** to pop up the modifying device information window.


It is recommended to leave these settings as default unless instructed to change by Ness Technical staff.

Click **Wiegand-485 Settings** tab to enter the Wiegand settings interface.

Note: The Wiegand Settings should be supported by the device.

Steps:

1. Click the **Wiegand Settings** tab to enter the Wiegand Settings interface.



The screenshot shows a settings window with two dropdown menus. The first dropdown is labeled 'Wiegand No.' and has '1' selected. The second dropdown is labeled 'Communication Direction' and has 'Receive' selected. Below the dropdowns is a 'Save' button.

2. Select the Wiegand channel No. and the communication mode in the dropdown list.
If you set the **Communication Direction** as **Send**, you are required to set the Wiegand Mode as Wiegand 26 or Wiegand 34.
3. Click **Save** to save the settings and the configured parameters will be applied to the device automatically.

Note: After changing the communication direction, the device will be rebooted. A prompt will be popped up after changing the communication direction.

7.4.7 M1 Card Encryption

It is recommended to leave these settings as default unless instructed to change by Ness Technical staff.

The M1 Card Encryption function increases the authentication security level, which should be applied together with the card enrollment station of our company via the client software or the web client. After issuing the card, you can set the M1 card encryption function on the controller.

Notes:

- The function should be supported by the device.
- For details about issuing card, refer to *Adding Person (Card)* in *4 In the organization list* on the left, you should add a top organization as the parent organization of all organizations. Click **Add** button to pop up the adding organization interface.



1. Input the Organization Name as desired.
2. Click **OK** to save the adding.
3. You can add multiple levels of organizations according to the actual needs.
To add sub organizations, select the parent organization and click **Add**.
Repeat *Step 2* and *3* to add the sub organization.
Then the added organization will be the sub-organization of the upper-level organization.

Note: Up to 10 levels of organizations can be created.

Modifying and Deleting Organization

You can select the added organization and click **Modify** to modify its name.

You can select an organization, and click **Delete** button to delete it.

Notes:


- The lower-level organizations will be deleted as well if you delete an organization.
- Make sure there is no person added under the organization, or the organization cannot be deleted.
- Person Management.

Select the device in the device list, and click **Modify** to pop up the modifying device information window.

Click **M1 Card Encryption** tab to enter the M1 Card Encryption interface.

Steps:

1. In the M1 Card Encryption interface, check **Enable** checkbox to enable the M1 card encryption function.




2. Set the sector ID.
3. Click **Save** to save the settings.

Note: The sector ID ranges from 1 to 100.

7.4.8 Remote Configuration

Purpose:


In the device list, select the device and click **Remote Configuration** button to enter the remote configuration interface. You can set the detailed parameters of the selected device.



Checking Device Information

Steps:

1. Click **System** -> **Device Information** to check the device basic information and the device version information.



Editing Device Name

In the Remote Configuration interface, click **System** -> **General** to configure the device name and overwrite record files parameter. Click **Save** to save the settings.

Configuring the General Parameters

Device Information

Device Name:

Device No.:

Editing Time

Steps:

1. In the Remote Configuration interface, click **System** -> **Time** to configure the time zone.
2. (Optional) Check **Enable NTP** and configure the NTP server address, the NTP port, and the synchronization interval.
3. (Optional) Check **Enable DST** and configure the DST star time, end time and the bias.
4. Click **Save** to save the settings.

Remote Configuration

Configuring the Time Settings (e.g., NTP, DST)

Time Zone

Select Time Zone:

Enable NTP

Server Address:

NTP Port:

Sync Interval: Minute(s)

Enable DST

Start Time: :00

End Time: :00

DST Bias:

Setting System Maintenance

Steps:

1. In the Remote Configuration interface, click **System** -> **System Maintenance**.
2. Click **Reboot** to reboot the device.
Or click **Restore Default Settings** to restore the device settings to the default ones, excluding the IP address.
Or click **Restore All** to restore the device parameters to the default ones. The device should be activated after restoring.

Note: The configuration file contains the device parameters.

3. You can also remote upgrade the device.
 - 1) In the Remote Upgrade part, select an upgrade file type in the dropdown list.
You can select Controller Upgrade File or Card Reader Upgrade in the drop-down list.
 - 2) Click to select the upgrade file.
 - 3) Click **Upgrade** to start upgrading.

Note: Only card readers connected via RS-485 can be upgraded.

The screenshot shows the 'System Maintenance' window. Under the 'System Management' section, there are buttons for 'Reboot', 'Restore Default Settings', and 'Restore All'. The 'Remote Upgrade' section contains a 'Select Type' dropdown menu set to 'Controller Upgrade ...', a 'Select File' input field with a file selection button (...), an 'Upgrade' button, and a 'Progress' progress bar.

Setting Security

Steps:


1. Click **System** -> **Security**.

The screenshot shows the 'Configuring the Security Parameters' window. Under the 'Encryption Mode' section, there is a 'Level' dropdown menu set to 'Compatible Mode' and a 'Save' button.

2. Select the encryption mode in the dropdown list.
You can select Compatible Mode or Encryption Mode.
3. Click **Save** to save the settings.

Configuring Network Parameters


Click **Network** -> **General**. You can configure the NIC type, the IPv4 address, the subnet mask (IPv4), the default gateway (IPv4), MTU address, MTU, and the device port. Click **Save** to save the settings.



Configuring Access Control Parameters

Steps:


1. In the Remote Configuration interface, click **Other -> Access Control Parameters**.
2. Select and check the **Downstream RS-485 Communication Backup** checkbox or the **Press Key to Input Card No.** checkbox.
3. Click **Save** to save the settings.



Person and Card Management

You can add, edit, and delete the organization and person in Person and Card Management module.

From the 'Access Control' Module, Click  tab to enter the Person and Card Management interface.



The interface is divided into two parts: Organization Management and Person Management.


1	Organization Management	You can add, edit, or delete the organization as desired.
2	Person Management	After adding the organization, you can add the person to the organization and issue card to persons for further management.

7.4.1 Organization Management

Adding Organization

Steps:

- In the organization list on the left, you should add a top organization as the parent organization of all organizations.
Click **Add** button to pop up the adding organization interface.



- Input the Organization Name as desired.
- Click **OK** to save the adding.
- You can add multiple levels of organizations according to the actual needs.

To add sub organizations, select the parent organization and click **Add**.
 Repeat *Step 2* and *3* to add the sub organization.
 Then the added organization will be the sub-organization of the upper-level organization.

Note: Up to 10 levels of organizations can be created.

Modifying and Deleting Organization

You can select the added organization and click **Modify** to modify its name.
 You can select an organization, and click **Delete** button to delete it.

Notes:

- The lower-level organizations will be deleted as well if you delete an organization.
- Make sure there is no person added under the organization, or the organization cannot be deleted.

7.4.2 Person Management


After adding the organization, you can add person to the organization and manage the added person such as issuing cards in batch, importing and exporting person’s information in batch, etc.

Note: Up to 100,000 persons or cards can be added.

Adding Person / Card

Steps:

1. Select an organization in the organization list and click **Add** button on the Person panel to pop up the adding person dialog.



1. The Person No. will be generated automatically and is not editable.
2. Input the persons information as required. (i.e. Person name, gender, phone No., date of Birth, and email etc to suit the client’s actual needs. This is database information for the customer and will work without this information)
3. Click **Upload Picture** to select the person picture from the local PC to upload it to the client.
Note: The picture should be in *.jpg format.
 (Optional) You can also click **Take Photo** to take the person’s photo with the PC camera.
4. Click **OK** to finish adding.

Adding Person (Detailed Information)

Steps:

1. In the Add Person interface, click **Details** tab.

2. Input the detailed information of the person, including person’s ID type, ID No., country, etc., according to actual needs.
 - **Linked Device:** You can bind the Intercom indoor station to the person.
Note: If you select **Analog Indoor Station** in the Linked Device, the **Door Station** field will

display and you are required to select the door station to communicate with the analog indoor station.

- **Room No.:** You can input the room No. of the person, as used with the Apartment Intercom System. .

3. Click **OK** to save the settings.


Adding Person (Permission / Access Levels)

Note: Before Permissions can be set to a user, they first need to be set. For setting the access control permission, so they can be used, refer to *Chapter 7.6 Permission Configuration*.


Once access permissions are created, you can assign the permissions (ie. What doors the user can access during what times) to the person when adding person.

Steps:

1. In the Add Person interface, click **Permission** tab.



2. In the 'Permission(s) to Select list', all the configured permissions are displayed. Check the permission(s) checkbox(es) and click > to add to the Selected Permission(s) list. (Optional) You can click >> to add all the displayed permissions to the Selected Permission(s) list.



(Optional) In the Selected Permission(s) list, select the selected permission and click < to remove it. You can also click << to remove all the selected permissions.



3. Click **OK** to save the settings.

Adding Person (Card / Credential)


You can add card and issue the card to the person.

Steps:

1. In the Add Person interface, click **Credential** tab, then click “Card” tab to add an Access Card.



2. Click **Add** to pop up the Add Card dialog.




3. Select the card type according to actual needs.

- **Normal Card**
- **Card for Disabled Person:** The door will remain open for the configured time period for the card holder.
- **Card in Blacklist:** The card swiping action will be uploaded and the door cannot be opened.
- **Patrol Card:** The card swiping action can be used for checking the working status of the Guard Patrol. The access permission of the Guard Patrol staff is configurable.
- **Duress Card:** The door can be opened by swiping the duress card when there is duress. At the same time, the client can report the duress event.
- **Super Card:** The card is valid for all the doors of the controller during the configured schedule.
- **Visitor Card:** The card is assigned for visitors. For the Visitor Card, you can set the **Max. Swipe Times**.


Notes for Visitor Card:



- The Max. Swipe Times should be between 0 and 255. When your swiping card times is more than the configured times, card swiping will be invalid.
- When set the times as 0, it means the card swiping is unlimited.



4. Input the password (PIN No) of the card itself in the Card Password field. The card password should contain 4 to 8 digits.

Note: The password will be required when the card holder swiping the card to get enter to or exit from the door if you enable the card reader authentication mode as **Card and Password**, **Password and Fingerprint**, and **Card, Password, and Fingerprint**. For details, *Chapter 7.7.2 Card Reader Authentication*.

5. Click  to set the effective time and expiry time of the card.

Effective Period: From 2018-02-28 10:40:21  To 2028-02-28 10:40:21 

6. Select the **Card Reader Mode** for reading the card No.

A card can be entered into the system in 3 different ways.

1. Via the Controllers card reader (any reader on the system)
2. Via an Enrollement reader connected via a USB port to the clients PC running iVMS4200 software. (e.g. DS-K1F180-D8E)



3. Manually entering the full card Number (e.g. 8 digits – 3 Digit Site code followed by 5 digit card No.)

- **Access Controller Reader:** Select “Read” and then place the card on the reader of the Access Controller to get the card No.

Card Enrollment Station: Select “Read” and then place the card on the Card Enrollment Station to get the card No.

Note: The Card Enrollment Station should connect with the PC running the client. You first need to click **Set Card Enrollment Station** to enter the following dialog to set it up before reading a card.

- 2) Select the Card Enrollment Station type.
- 3) **Note:** Currently, the supported card reader types include DS-K1F100-D8E and **DS-K1F180-D8E**
- 4) Set the serial port No., the baud rate, the timeout value, the buzzing, or the card No. type.
- 5) If using standard 26 Bit Wiegand Cards, then set the Card No. Type to Wiegand.

If the card is M1 card, and if you need to enable the M1 Card Encryption function, you should check **Enable** checkbox of M1 Card Encryption and click **Modify** to select the sector.

- 6) Click **Save** button to save the settings.

You can click Restore Default Value button to restore the defaults.

Understanding Card Markings.

Depending on the card vendor, there may be a 10 Digit Card No, 8 Digit (with comma after the first 3 digits) or both 10 and 8 Digit numbers on the card.

There are usually two sets of numbers on the 125kHz EM4100 RFID cards. Key fobs usually only have a single 10-digit or Single 8-digit number.

e.g.



The number on the right, "**comma format**": (e.g. 123, 45678)

- This is usually the Cards **26 Bit Wiegand Number**. It consists of a 3 Digit Site Code (0-255) and then a 5 Digit Card No (0-65,535).
- According to the Wiegand 26 spec, this is the badge number in this format.

The number on the left, "**10-digit format**": (e.g. 0123456789)

- If the Card Reader is set to output **34 Bit Wiegand**, then often this is the associated Card No.

- **Manually Input:** Input the card No. and click **Enter** to input the card No.
7. Click **OK** and the card(s) will be issued to the person.
 8. (Optional) You can select the added card and click **Edit** or **Delete** to edit or delete the card.
 9. (Optional) You can click **Link Fingerprint** to link the card with the person's fingerprint, so that the person can place the finger on the scanner instead of swiping card when passing the door.
 10. Click **OK** to save the settings.

Adding Person (Fingerprint)


To program Fingerprint into the system, you require a Fingerprint Registration Terminal.



DS-K1F820-F


Steps:

1. In the Add Person interface, click **Fingerprint** tab.



- Before inputting the fingerprint, you should connect the fingerprint machine to the PC and set its parameters first.


Click **Set Fingerprint Machine** to enter the following dialog box.



- Select the device type: **DS-K1F820-F**
- Click **Save** button to save the settings.


You can click **Restore Default Value** button to restore the default settings.

- Click on the first Finger you wish to register,




- Click **Start** button, click to select the fingerprint to start collecting.
- Lift and rest the corresponding fingerprint on the fingerprint scanner twice to collect the fingerprint to the client.
- Click **Stop** button can stop collecting.
- After collecting the fingerprint, click 'Card' in the Add Person window to enter the Card tab. You can select the registered fingerprint and click **Delete** to delete it. You can click **Clear** to clear all fingerprints.
- Click **OK** to save the fingerprints.

9. Click **Link Fingerprint** to link the fingerprint to the card.



Select the Fingerprints you wish to link to the added card and then click "OK".




Adding Person (Attendance Rule)

You can set the attendance rule for the person.


Note: This tab page will display when you select **Non-Residence** mode in the application scene when running the software for the first time.

Steps:

1. In the Add Person interface, click **Attendance Rule** tab.



2. If the person joins in the time and attendance, check the **Time and Attendance** checkbox to enable this function for the person. Then the person's card swiping records will be recorded and analyzed for time and attendance.
For details about Time and Attendance, click **More** to go to the Time and Attendance module.
3. Click **OK** to save the settings.
4. Once the person's details have been saved, if the changes affect the access to doors / readers etc, then a 'Data Synchronise' dialog box will open to allow you to download / synchronize the changes into the controller.




5. Click 'apply now' to download the changes to the controller(s)

Importing and Exporting Person Information

The person information can be imported and exported in batch.

Steps:


1. **Exporting Person:** You can export the added persons' information in Excel format to the local PC.
 - 1) After adding the person, you can click **Export Person** button in the Person and Card tab to pop up the following dialog.
 - 2) Click to select the path of saving the exported Excel file.
 - 3) Check the checkboxes to select the person information to export.



- 4) Click **OK** to start exporting.

2. **Importing Person:** You can import the Excel file with persons information in batch from the local PC

1) click **Import Person** button in the Person and Card tab.



2) You can click **Download Template for Importing Person** to download the template first.

3) Input the person information to the downloaded template.

4) Click **...** to select the Excel file with person information.

5) Click **OK** to start importing.

To bulk add cards into the system, export the file, modify it with all the card numbers you want to add and then import it into the system.

Getting Person Information from Access Control Device


If the added access control device has been configured with person information (including person details, fingerprint, issued card information), you can get the person information from the device and import to the client for further operation.

Note: This function is only supported by the device the connection method of which is TCP/IP when adding the device.

Steps:

1. In the organization list on the left, click to select an organization to import the persons.

2. Click **Get Person** button to pop up the following dialog box.



3. The added access control device will be displayed.

4. Click to select the device and then click **OK** to start getting the person information from the device.



You can also double click the device name to start getting the person information.


Notes:

- The person information, including person details, person’s fingerprint information (if configured), and the linked card (if configured), will be imported to the selected organization.
- If the person name stored in the device is empty, the person name will be filled with the issued card No. after importing to the client.
- The gender of the persons will be **Male** by default.
- Up to 10,000 persons with up to 5 cards each can be imported.


Managing Person

Modifying and Deleting Person

To modify the person information and attendance rule, click  or  in the Operation column, or select the person and click **Modify** to open the editing person dialog.



You can click  to view the person’s card swiping records.



To delete the person, select a person and click **Delete** to delete it.


Note: If a card is issued to the current person, the linkage will be invalid after the person is deleted.

Changing Person to Other Organization

You can move the person to another organization if needed.

Steps:

1. Select the person in the list and click **Change Organization** button.



2. Select the organization to move the person to.
3. Click **OK** to save the settings.

Issuing Card in Batch

You can issue multiple cards for the person with no card issued in batch.

Steps:

1. Click **Issue Card in Batch** button to enter the following dialog.

All the added person with no card issued will display in the Person(s) with No Card Issued list.

Person(s) with No Card Issued			Person(s) with Card Issued			
Person Name	Gender	Department	Person Name	Card No.	Gender	Departm
Wendy	Female	Department 1				
Cindy	Female	Department 1/Sub Depar...				

2. Select the card type according to actual needs.

Note: For details about the card type, refer to *Adding Person*.

3. Input the password of the card itself in the Card Password field. The card password should contain 4 to 8 digits.

Note: The password will be required when the card holder swiping the card to get enter to or exit from the door if you enable the card reader authentication mode as **Card and Password**, **Password and Fingerprint**, and **Card, Password, and Fingerprint**. For details, refer to *Chapter 7.7.2 Card Reader Authentication*.

4. Input the card quantity issued for each person.

For example, if the Card Quantity is 3, you can read or enter three card No. for each person.


5. Click to set the effective time and expiry time of the card.

6. Select the Card Reader Mode for reading the card No.

- **Access Controller Reader:** Place the card on the reader of the Access Controller and click **Read** to get the card No.

- **Card Enrollment Station:** Place the card on the Card Enrollment Station and click **Read** to get the card No.

Note: The Card Enrollment Station should connect with the PC running the client. You can click **Set Card Enrollment Station** to enter the following dialog.



- 1) Select the Card Enrollment Station type.
- 2) Currently, the supported card reader types include DS-K1F100-D8E and **DS-K1F180-D8E**
- 3) Set the parameters about the connected card enrollment station.
If the card is M1 card, and if you need to enable the M1 Card Encryption function, you should check **Enable** checkbox of M1 Card Encryption and click **Modify** to select the sector.
- 4) Click **Save** button to save the settings.

You can click **Restore Default Value** button to restore the defaults.

- **Manually Input:** Input the card No. and click **Enter** to input the card No.


7. After issuing the card to the person, the person and card information will display in the Person(s) with Card Issued list.
8. Click **OK** to save the settings.


7.5 Schedule and Template

Purpose:

Schedules allow you to set what times and day's events will occur. E.g. Door Auto unlocking, what times card holder can access doors etc.

You can configure the template including a week's schedule and holiday schedule. After setting the templates, you can adopt the configured templates to access control permissions when setting the permission. The access control permissions will take effect in the time durations of the template.

Click  to enter the schedule and template interface.



You can manage the schedule of access control permission including Week Schedule, Holiday Schedule, and Template. For permission settings, please refer to *Chapter 7.6 Permission Configuration*.

7.5.1 Week Schedule

Click **Week Schedule** tab to enter the Week Schedule Management interface.


The client defines two kinds of week plan by default: **Whole Week Schedule** and **Blank Schedule**, which cannot be deleted and edited.

- **Whole Week Schedule:** Card swiping is valid on each day of the week.
- **Blank Schedule:** Card swiping is invalid on each day of the week.

You can perform the following steps to define custom schedules on your demand.


Steps:


1. Click **Add Week Schedule** button to pop up the adding schedule interface.





2. Input a name of week schedule (e.g. Office Access Hours) and click **OK** button to add the week schedule.
3. Select the 'added week schedule' in the schedule list and you can view its property on the right.

You can edit the week schedule name and input the remark / comment information for future reference.

4. On the week schedule, click and drag on a day to draw on the schedule, which means in that period of time, the configured permission is activated. 




Note: Up to 8 time periods can be set for each day in the schedule.

5. When the cursor turns to , you can move the selected time bar you just edited. You can also edit the displayed time point to set the accurate time period. When the cursor turns to , you can lengthen or shorten the selected time bar.
6. Optionally, you can select the schedule time bar, and then click **Delete Duration** to delete the selected time bar, or click **Clear** to delete all the time bars, or click **Copy to Week** to copy the time bar settings to the whole week.
7. Click **Save** to save the settings.


7.5.2 Holiday Group

Click **Holiday Group** tab to enter the Holiday Group Management interface.




Steps:

1. Click **Add Holiday Group** button on the left to pop up the adding holiday group interface.








2. Input the name of holiday group in the text field and click **OK** button to add the holiday group.
3. Select the added holiday group and you can edit the holiday group name and input the remark information.
4. Click **Add Holiday** icon on the right to add a holiday period to the holiday list and configure the duration of the holiday.

Note: Up to 16 holidays can be added to one holiday group.



- 1) On the period schedule, click and drag to draw the period, which means in that period of time, the configured permission is activated.

Note: Up to 8 time durations can be set for each period in the schedule.

- 2) When the cursor turns to , you can move the selected time bar you just edited. You can also edit the displayed time point to set the accurate time period.
- 3) When the cursor turns to , you can lengthen or shorten the selected time bar.
- 4) Optionally, you can select the schedule time bar, and then click  to delete the selected time bar, or click  to delete all the time bars of the holiday, or click  to delete the holiday directly.

5. Click **Save** to save the settings.


Note: The holidays cannot be overlapped with each other.

7.5.3 Template

After setting the week schedule and holiday group, you can configure the template which contains week schedule and holiday group schedule.

Note: The priority of holiday group schedule is higher than the week schedule.

Click **Template** tab to enter the Template Management interface.





There are two pre-defined templates by default: **Whole Week Template** and **Blank Template**, which cannot be deleted and edited.

- **Whole Week Template:** The card swiping is valid on each day of the week and it has no holiday group schedule.
- **Blank Template:** The card swiping is invalid on each day of the week and it has no holiday group schedule.


You can define custom templates on your demand.



Steps:

1. Click **Add Template** to pop up the adding template interface.



2. Input the template name (for future use that makes easier reference in the future) in the text field and click **OK** button to add the template.
3. Select the added template (from the left hand window) and you can edit its property on the right. You can edit the template name and input the remark information.
4. Select a week schedule to apply to the schedule. Click **Week Schedule** tab and select a schedule in the dropdown list.








You can also click **+ Add Week Schedule** to add a new week schedule. For details, refer to *Chapter 7.5.1 Week Schedule*.

5. Select holiday groups to apply to the schedule.

Note: Up to 4 holiday groups can be added.



Click to select a holiday group in the list and click **Add** to add it to the template. You can also click **Add Holiday Group** to add a new one from this screen. For details, refer to *Chapter 5*.
 When the cursor turns to , you can move the selected time bar you just edited. You can also edit the displayed time point to set the accurate time period.
 When the cursor turns to , you can lengthen or shorten the selected time bar.

8. Optionally, you can select the schedule time bar, and then click **Delete Duration** to delete the selected time bar, or click **Clear** to delete all the time bars, or click **Copy to Week** to copy the time bar settings to the whole week.
9. Click **Save** to save the settings.

Holiday Group.

You can click to select an added holiday group in the right-side list and click **Delete** to delete it. You can click **Clear** to delete all the added holiday groups.

6. Click **Save** button to save the settings.

7.6 Permission Configuration

In Permission Configuration module, you can add, edit, and delete the access control permission, and then apply the permission settings to the device to take effect.

Click  icon to enter the Access Control Permission interface.

+ Add ✎ Modify ✖ Delete 🔒 Apply to Device					
Permission Name	Template	Person	Door	Details	Status
Door 2 Permissi...	Whole Week Te...	Wendy	Door Station	Details	Not Applied
Door 1 Permissi...	Whole Week Te...	Wendy,Yining	Door1_10.16.6.1...	Details	Applying failed

C O R P O R A T I O N


7.6.1 Adding Permission

Purpose:

You can assign permission for persons to enter/exist the access control points (doors) in this section.

Steps:

1. Click **Add** icon to enter following interface.



2. In the Permission Name field, input the name for the permission as desired.
3. Click on the dropdown menu to select a template for the permission. (e.g. Office Hours)

Note: You should configure the Schedule Template before permission settings. You can click **Add Template** button from this screen to add the template. Refer to *Chapter 7.5 Schedule and Template* for details.

In the Person list, all the added persons are displayed. Select the persons for this Permission Group.

Note: Once Permissions are added, you can also assign the persons to their permissions from the Add / Modify persons Card section. Refer to [Chapter 7.5.2 Adding Person \(Permission / Access Levels\)](#) for details.
4. Check the checkbox(s) to select person(s) and click > to add to the Selected Person list. (Optional) You can select the person in Selected Person list and click < to cancel the selection.
5. In the Access Control Point/Device list, all the added access control points (doors) and door stations will display. Check the checkbox(s) to select door(s) or door station(s) the person(s) will have access to and click > to add to the selected list. (Optional) You can select the door or door station in the selected list and click < to cancel the selection.

6. Click **OK** button to complete the permission adding. The selected person will have the permission to enter/exit the selected door/door station with their linked card(s).
7. (Optional) after adding the permission, you can click **Details** to modify it. Or you can select the permission and click **Modify** to modify.
You can select the added permission in the list and click **Delete** to delete it.


7.6.2 Applying Permission

Purpose:

After configuring the permissions, you should apply the added permission to the access control device to take effect.

Steps:

1. Select the permission(s) to apply to the access control device. To select multiple permissions, you can hold the *Ctrl* or *Shift* key and select permissions.
2. Click **Apply to Device** to start applying the selected permission(s) to the access control device or door station.
3. The following window will pop up, indicating the applying permission result.





7.7 Advanced Functions

Purpose:

After configuring the person, template, and access control permission, you can configure the advanced functions of access control application, such as access control parameters, authentication password, and opening door with first card, anti-passing back, etc.

Note: The advanced functions should be supported by the device.

Click  icon to enter the following interface.



7.7.1 Access Control Parameters


Purpose:


After adding the access control device, you can configure its access control point (door)'s parameters, and its card readers' parameters.

Click **Access Control Parameters** tab to enter the parameters settings interface.

Door Parameters

Steps:

1. In the controller list on the left, click  to expand the access control device, select the door (access control point) and you can edit the information of the selected door on the right.



2. You can editing the following parameters:

Door Magnetic: (reed switch for monitoring the state (open/close) of the door. When using door monitoring with a N/C Reed Switch, then select '**Remain Closed**'. If not monitoring the state of the door with a N/C Reed switch then have it set to "**Remain Open**" (Normally Open condition).

Exit Button Type: Sets the "Request to Exit Button Type" : If the exit button has a Normally Open contact then set this to "**Remain Open**" and if it uses a Normally Closed contact then set this to "**Remain Close**".

Door Locked Time: This is the time the door lock Output will stay activated for (Door unlocked for) after a valid Card read.

Door Open Duration by Card for Disabled Person: This is the time the door lock Output will stay activated for (Door unlocked for) after a valid Card read by a user assigned as disabled.

Door Open Timeout Alarm: The alarm can be triggered if the door has not been closed (i.e. Door open too long). The time set here sets how long the door can remain opened for after a valid card read, or Request to Exit button activation before the door open timeout alarm will activate.

Enable Locking Door when Door Closed: The door can be locked once it is closed even if the Door Locked Time is not reached.

Duress Code: The door can open by inputting the duress code when there is duress. At the same time, the client software can receive the duress event.

Super Password: The specific person can open the door by inputting the super password.

Dismiss Code: Input the dismiss code to stop the buzzer of the card reader.

Notes:


- The duress code, Super password, and dismiss code should be different.
- The duress code, super password, and the dismiss code should be different from the authentication password.
- The duress code, super password, and the dismiss code should contain 4 to 8 digits.

AUTO UNLOCKING OF DOORS

Purpose:

You can schedule weekly time periods for an access control point (door) to remain open or remain closed.

In the Door Status module, click **Status Duration** button to enter the Status Duration interface.





Steps:

1. Click to select a door from the access control device list on the left.
 2. On the Door Status Configuration panel on the right, draw a schedule for the selected door.
 - A. Select a door status brush as Remain Open or Remain Closed .
 - a. **Remain Open:** The door will keep open during the configured time period. The brush is marked as .
 - b. **Remain Closed:** The door will keep closed during the configured duration. The brush is marked as .
- NOTE: Use “Remain Closed” with caution. During the ‘Remain Closed times (if programmed) the door will be in ‘lock down’ mode and Cards will also not work during this time. Unless ‘lock down’ operations is required, we recommend only use time in the ‘Remain Open’ time to Auto Unlock the door and outside these times the door will auto relock.

B. Click and drag on the timeline to draw a colour bar on the schedule to set the duration.



C. When the cursor turns to , you can move the selected time bar you just edited. You can also edit the displayed time point to set the accurate time period.


When the cursor turns to , you can lengthen or shorten the selected time bar.


3. Optionally, you can select the schedule time bar and click **Copy to Whole Week** to copy the time bar settings to the other days in the week.
4. You can select the time bar and click **Delete Duration** to delete the time period. Or you can click **Clear** to clear all configured durations on the schedule.
5. Click **Save** to save the settings.
6. You can click **Copy to** button to copy the schedule to other doors.
7. Click **Save** button to save parameters.

Note: You can also set the auto unlock time to be disabled until the 'First Card' has been used at the premises. This will prevent doors being auto unlocked if no staff member is onsite. Refer 'First Card' feature on page 88.

Card Reader Parameters

Steps:

1. In the device list on the left, click  to expand the door, select the card reader name and you can edit the card reader parameters on the right.



2. You can editing the following parameters:

Nickname: Edit the card reader name as desired. (e.g. Front Door Entry Reader)

Enable Card Reader: Select **Yes** to enable the card reader.

OK LED Polarity: Select the OK LED Polarity of the card reader main board.

Error LED Polarity: Select the Error LED Polarity of the card reader main board.

Buzzer Polarity: Select the Buzzer LED Polarity of the card reader main board.

Minimum Card Swiping Interval: This sets the minimum time between card Reads. If a card is read after another less than this set time, the card swiping is invalid. You can set it as 0 to 255.

Max. Interval When Inputting Password: When you inputting the password on the card reader, if the interval between pressing two digits is larger than the set value, the digits you pressed before will be cleared automatically.

Enable Failed Attempts Limit of Card Reading: Enable to report alarm when the card reading attempts reach the set value.

Max. Times of Card Swiping Failure: Set the max failure attempts of reading card.

Enable Tampering Detection: Enable the anti-tamper detection for the card reader. (Used with RS485 Readers)

Detect When Card Reader is Offline for: When the access control device cannot connect with the card reader for longer than the set time, the card reader will turn offline automatically. (Used with RS485 Readers).

Fingerprint Recongnition Level: Sets the Fingerprint level for when Fingerprint readers are used.

Card Reader Type: If a RS485 reader is used, this filed will automatically be filled by the system showing the type of reader.

Card Reader Description: If a RS485 reader is used, this filed will automatically be filled by the

system showing the description of the reader.

Buzzer Time: sets how long the reader buzzer will pulse for if programmed to pulse.

3. Click the **Save** button to save parameters.

7.7.2 Card Reader Authentication


Purpose:

You can set what credential is required and during what time for access to be granted.

E.g. Card only during office hours and Card AND Code after hours. This is set for each controller entry point.

Steps:

1. Click **Card Reader Authentication** tab and select a reader on the left.




2. Select a card reader authentication mode. The available authentication modes depend on the card reader type:

To see what available options you have for the selected Controller and Reader, click on 'Configure' on the top right of the screen.




All available options for your Controller and Reader will be displayed on the left hand window in the 'Selectable Mode' column. Select the option you want to use from the 'Selectable Mode'


column and then select click on the  to add them to the 'Selected Mode'.



Once selected, you can then set them in the required order they will appear in the settings page by using the up and down arrows options.




They will then display in the order you selected.



The following possible options are dependent on the Controller and Reader you have.

- **Card:** The door can be unlocked by presenting a Valid Card only.
 - **Card and Password:** The door can open by both inputting the card password and swiping the card.
- Note:** Here the password refers to the password set when issuing the card to the person. *Chapter 4* In the organization list on the left, you should add a top organization as the parent organization of all organizations.

Click **Add** button to pop up the adding organization interface.



8. Input the Organization Name as desired.
9. Click **OK** to save the adding.
10. You can add multiple levels of organizations according to the actual needs.

To add sub organizations, select the parent organization and click **Add**.
 Repeat *Step 2* and *3* to add the sub organization.
 Then the added organization will be the sub-organization of the upper-level organization.

Note: Up to 10 levels of organizations can be created.

Modifying and Deleting Organization

You can select the added organization and click **Modify** to modify its name.
 You can select an organization, and click **Delete** button to delete it.

Notes:

- The lower-level organizations will be deleted as well if you delete an organization.
- Make sure there is no person added under the organization, or the organization cannot be deleted.

Person Management.


- **Card or Authentication Password:** The door can open by inputting the authentication password (PIN ONLY) or swiping the card.

Note: Here the authentication password refers to the password set to open the door. Refer to *Chapter 7.7.8 Authentication Password*.

- **Fingerprint:** The door can open by only inputting the fingerprint.
- **Card or Fingerprint:** The door can open by inputting the fingerprint or swiping the card.
- **Password and Fingerprint:** The door can open by both inputting the card password and inputting the fingerprint.

Note: Here the password refers to the card password set when issuing the card to the person. Refer to *Chapter 4 In the organization list on the left, you should add a top organization as the parent organization of all organizations.*

Click **Add** button to pop up the adding organization interface.



11. Input the Organization Name as desired.
12. Click **OK** to save the adding.
13. You can add multiple levels of organizations according to the actual needs.

To add sub organizations, select the parent organization and click **Add**.
 Repeat *Step 2* and *3* to add the sub organization.
 Then the added organization will be the sub-organization of the upper-level organization.

Note: Up to 10 levels of organizations can be created.

Modifying and Deleting Organization

You can select the added organization and click **Modify** to modify its name.
 You can select an organization, and click **Delete** button to delete it.

Notes:


- The lower-level organizations will be deleted as well if you delete an organization.
- Make sure there is no person added under the organization, or the organization cannot be deleted.

Person Management.

- **Card and Fingerprint:** The door can open by both inputting the fingerprint and swiping the card.
- **Card, Password and Fingerprint:** The door can open by inputting the fingerprint, inputting the card password, and swiping the card.

Note: Here the password refers to the card password set when issuing the card to the person. Refer to *Chapter 4 In the organization list on the left, you should add a top organization as the parent organization of all organizations.*

Click **Add** button to pop up the adding organization interface.



14. Input the Organization Name as desired.
15. Click **OK** to save the adding.
16. You can add multiple levels of organizations according to the actual needs.
To add sub organizations, select the parent organization and click **Add**.
Repeat *Step 2* and *3* to add the sub organization.
Then the added organization will be the sub-organization of the upper-level organization.

Note: Up to 10 levels of organizations can be created.

Modifying and Deleting Organization

You can select the added organization and click **Modify** to modify its name.


You can select an organization, and click **Delete** button to delete it.

Notes:


- The lower-level organizations will be deleted as well if you delete an organization.
- Make sure there is no person added under the organization, or the organization cannot be deleted.

Person Management.

3. Select the required method for unlocking the door lock and then “click and drag” your mouse on a day to draw a color bar on the schedule. The ‘drawn / selected’ hours means in that period of time, the card reader authentication is valid.
e.g.





4. Repeat the above step to set other time periods.
 Or you can select a configured day and click **Copy to Week** button (from the top right of the window) to copy the same settings to the whole week.
 (Optional) You can click **Delete** button to delete the selected time period or click **Clear** button to delete all the configured time periods.



(Optional) You can click **Delete** button to delete the selected time period or click **Clear** button to delete all the configured time periods.

5. (Optional) Click **Copy to** button to copy the settings to other card readers.



6. Click **Save** button to save parameters.

7.7.3 Multiple Authentication


Purpose:

You can manage the cards by group and set the authentication for multiple cards for one access control point (door).

Note: Please set the card permission and apply the permission setting to the access control device first. For details, refer to *Chapter 7.6 Permission Configuration*.


Steps:


1. Click **Multiple Authentication** tab to enter the following interface.




2. Select access control device from the list on the left.

3. In the Set Card Group panel on the right, click **Add** button to pop up the following dialog:



- 1) In the Card Group Name field, input the name for the group as desired.
- 2) Click  to set the effective time and expiry time of the card group.
- 3) Check the checkbox(es) to select the card(s) to add the card group.
- 4) Click **OK** to save the card group.

4. In the Set Authentication Group panel on the left, click **Add** to pop up the following dialog.



- 1) Select the access control point (door) of the device for multiple authentications.
- 2) Input the time interval for card swiping.

- 3) Select the template of the authentication group from the dropdown list. For details about setting the template, refer to *Chapter 7.5 Schedule and Template*.
- 4) Select the authentication type of the authentication group from the dropdown list.
 - **Local Authentication:** Authentication by the access control device.
 - **Local Authentication and Remotely Open Door:** Authentication by the access control device and by the client.
For Local Authentication and Remotely Open Door type, you can check the checkbox to enable the super password authentication when the access control device is disconnected with the client.
 - **Local Authentication and Super Password:** Authentication by the access control device and by the super password.
- 5) In the list on the left, the added card group will display. You can click the card group and click **+** to add the group to the authentication group.
You can click the added card group and click **X** to remove it from the authentication group.
You can also click **↑** or **↓** to set the card swiping order.
- 5) Input the **Card Swiping Times** for the selected card group.

Notes:

- The Card Swiping Times should be larger than 0 and smaller than the added card quantity in the card group.
- The upper limit of Card Swiping Times is 16.

- 6) Click **OK** to save the settings.

5. Click **Save** to save and take effect of the new settings.

Notes:

- For each access control point (door), up to four authentication groups can be added.
- For the authentication group which certificate type is **Local Authentication**, up to 8 card groups can be added to the authentication group.
- For the authentication group which certificate type is **Local Authentication and Super Password** or **Local Authentication and Remotely Open Door**, up to 7 card groups can be added to the authentication group.

7.7.4 Open Door with First Card


Purpose:

‘Open Door with First Card’ has two features associated with it.

1. You can use this feature to disable the ‘Auto Unlocking’ of door from occurring until the First Card is used at that door.
2. You can set multiple first cards for one access control point (Door). After the first card is presented to the programmed reader, it allows multiple persons access through this control door point or other authentication actions.
The first card mode contains Remain Open with First Card or Disable Remain Open with First Card.

Option 1 – Disabling / Postpone ‘auto unlocking’ of doors

If you select a Door(s) to ‘Remain Open with First Card’ but do not assign any Cards (i.e. No card in the ‘first Card list’, then this feature will be used to ‘postpone Auto Unlocking of the door until any user uses their card at the door.




Example. If the door is programmed to Auto Unlock 9:00 am – 5:00 pm Mon-Fri (See Door Parameters ‘Auto Unlocking of Doors’ Page 77), but no one is onsite, i.e has not presented their card first at the door to be Auto Unlocked, then the auto Unlocking will be postponed / disabled until a valid card is first presented to the door to be auto unlocked.

If you wish to cancel / lock an Auto Unlocked door at any time with the above programmed, (e.g. Relock an Auto Unlocked door then a valid user can present their card 3 times within 5 seconds and the door will relock).

Note: the ‘Remain Open duration’ times are ignored if no cards are added to the ‘First Card List’

Option 2 – Remain Open by User

Remain Open with First Card: When a Card(s) / User is assigned / added to the ‘First Card List’ (as shown below) the door remains open for the configured time duration after the first card is presented until ‘the remain open duration’ expires.



Example. User arrives in the morning and presents his valid card at the door reader. The door then remains unlocked for the time programmed in the 'Remain Open Duration (Mins)' time. (e.g. 8 hours). At the expiry of this time (or if a card in the 'First Card List' is used again) the door will relock.

Notes:

- The Remain Open Duration should be between 0 and 1440 minutes. By default, it is 10 minutes.
- In the First Card Authorization mode, you can access the door when swiping a 'super card', a duress card or input the duress code without swiping the first card.
- You can swipe the first card again to disable the first card mode.
- The first card authorization is effective only on the current day. The authorization will be expired at midnight.

7.7.5 Anti-Passing Back

Purpose:

You can set anti-passing back for card readers in the same access controller. Anti-Passback prevents a card from "being passed back" for the same card to be used again at the same reader until it has been used a reader programmed for exiting the area. (e.g. Prevent a card from being used at a car park Entry Reader and then pass the card back to another person to allow them access. The card will be denied access when tried to be used a second time until it is used at an exit reader)


Notes:

- Either the anti-passing back **or** multi-door interlocking function can be configured for an access control device at the same time.
- You should enable the anti-passing back function on the access control device first.

Setting the Path of Swiping Card (Card Reader Order)

Steps:

1. Click **Anti-passing Back** tab to enter the following interface.




2. Select an access control device from the device list on the left.
Note: Not all controllers support Anti-Passback feature. E.g. It is not supported in the DS-K2800 series.

3. In the First Card Read... field, leave this as disable.

4. In 'Card Enrolment Station' List, select the reader that will register the person into an Area when their card is first presented (e.g. Into the Car Park). Then in the 'Card Reader Afterward' select from the dialog box the card reader(s) that is required to be used to register the person 'out' of the area (e.g. Out of the Car Park). You will need to also select the same reader from the "Card Enrolment Station" and select its "matching" reader to toggle out of the area.

Example: In the following example when a card is used and granted access at Reader 1 (Entrance Card Reader 1) it will register the card holder 'into' the area and if the same user attempted to present their card to Reader 1 again they will be denied access until they use their card at Reader 3 (Entrance Card Reader 3), and Visa Versa, once they use their card at Reader 3 (Entrance Card Reader 3), they can't use it again until after they use it at Reader 1 (Entrance Card Reader 1).



Notes:

- Up to four afterward card readers can be added for one card reader.
 - If a card is programmed as a "Super" Card the card is exempt from Anti-Passback rules.
5. (Optional) You can enter the Select Card Reader dialog box again to edit its afterward card readers.
6. Click **Save** to save and take effect of the new settings.

7.7.6 Cross-Controller Anti-passing Back


Purpose:

It is strongly recommended wherever possible to have Entry and Exit reader for Anti-Passback on one the one controller. However sometimes it is not possible. Therefore you can use the "Cross-Controller Anti-passing Back" feature.

You can set anti-passing back for card readers in multiple access controllers. You should swipe the card according to the configured swiping card route. And only one person could pass the access control point after swiping the card.

For the Cross-Controller Anti-passing Back” feature to operate iVMS4200 software must be running at all times.

Click **Cross-Controller Anti-passing Back** to enter the Cross-Controller Anti-passing Back tab.



Setting Route Anti-passing Back

Purpose:

The route anti-passing back depends on the card swiping route. You should set the first card reader and the card readers afterwards.


Steps:

3. Check the **Enable Cross-Controller Anti-passing Back** checkbox to enable the function.
4. Set the anti-passing back parameters.

➤ Based on Card

Note: The system will judge the anti-passing back according to the entrance and exit records on the card.

- 1) Select **Based on Card** as the anti-passing back mode in the drop-down list.
- 2) Select **Route Anti-passing Back** as the rule.
- 3) Set the sector ID.
- 4) Click **Select Device** to select a device in the pop-up window for anti-passing back authentication.
- 5) In the Set Card Reader area, click the icon on the left of the card enrollment station

column to select the first card reader. The icon will turn to .


- 6) Click the card reader afterward input field to select the card readers afterward in the pop-up window.
- 7) Check the checkbox in the Enable Anti-passing Back column to enable the anti-passing back function.

Notes:

- The displayed card readers in the card reader afterward input field should be in authentication order.
- Up to 64 controllers with anti-passing back function can be added.
- Up to 16 card readers afterward can be added for each card reader.
- It supports M1 card at present and the sector cannot be encrypted. For details about sector encryption, refers to 7.4.7 M1 Card Encryption.

➤ **Based on Network**

Note: Authenticate the anti-passing back according to the entrance and exit information on the card reader.

- 1) Select **Based on Network** as the anti-passing back mode in the drop-down list.
- 2) Select Route Anti-passing Back as the rule.
- 3) Select a server in the drop-down list for judging the anti-passing back.
- 4) (Optional) You can click **Delete Anti-passing Back Record** and select the card in the pop-up window to delete the card swiping information in all devices. The user should be start swiping card again from the first card reader.
- 5) In the Set Card Reader area, click the icon on the left of the card enrollment station column to select the first card reader. The icon will turn to .
- 6) Click the card reader afterward input field to select the card readers afterward in the pop-up window.
- 7) Check the checkbox in the Enable Anti-passing Back column to enable the anti-passing back function.

Notes:

- The displayed card readers in the card reader afterward input field should be in authentication order.
- Up to 64 controllers with anti-passing back function can be added.
- Up to 16 card readers afterward can be added for each card reader.
- Up to 5000 cards' swiping records can be stored in the selected server.

Setting Entrance/Exit Anti-passing Back

Purpose:

You can set the entrance card reader and the exit card reader only for entering and exiting, without setting the first card reader and the card readers afterwards.

Steps:

1. In the Cross-Controller Anti-passing Back tab, check the **Enable Cross-Controller Anti-passing Back** checkbox to enable the function.
2. Set the anti-passing back parameters.

➤ **Based on Card**

Note: The system will judge the anti-passing back according to the entrance and exit records on the card.

- 1) Select **Based on Card** as the anti-passing back mode in the drop-down list.
- 2) Select Entrance/Exit Anti-passing Back as the rule.
- 3) Set the sector ID.
- 4) Click **Select Device** to select a device in the pop-up window for anti-passing back authentication.
- 5) In the Set Card Reader area, check the checkboxes in the Enable Anti-passing Back column to select the entrance card reader and the exit card reader.
- 6) Click **Save** to save the settings.

Notes:

- Up to one entrance carder and one exit card reader should be checked.
- Up to 64 controllers with anti-passing back function can be added.
- It supports M1 card at present and the sector cannot be encrypted. For details about sector encryption, refers to [7.4.7 M1 Card Encryption](#).

➤ **Based on Network**

Note: Authenticate the anti-passing back according to the entrance and exit information on the card reader.

- 1) Select **Based on Network** as the anti-passing back mode in the drop-down list.
- 2) Select Entrance/Exit Anti-passing Back as the rule.
- 3) Select the server in the dropdown list for judging the anti-passing back.
- 4) (Optional) You can click **Delete Record** and select the card in the pop-up window to delete the card swiping information in all devices.
- 5) Click **Select Device** to select a device in the pop-up window for anti-passing back authentication.
- 6) In the Set Card Reader area, check the checkboxes in the Enable Anti-passing Back column to select the entrance card reader and the exit card reader.
- 7) Click **Save** to save the settings.

Notes:

- Up to one entrance carder and one exit card reader should be checked.
- Up to 64 controllers with anti-passing back function can be added.
- Up to 5000 cards' swiping records can be stored in the selected server.

7.7.7 Multi-door Interlocking

Purpose:

You can set the multi-door interlocking between multiple doors of the same access control device. To open one of the doors, other doors must keep closed. That means in the interlocking combined door group, up to one door can be opened at the same time.


Notes:

- The Multi-door Interlocking function is only supported by the access control device which has more than one access control points (doors).


- Either the anti-passing back or multi-door interlocking function can be configured for an access control device at the same time.

Steps:

1. Click **Multi-door Interlocking** tab to enter the multi-door interlock settings page.



2. Select an access controller from the Controller List.
3. Click **Add** to pop up the Add Access Control Point to Interlock interface.



4. Select the access control point (door) from the list.
 - Note:** Up to four doors can be added in one multi-door interlocking combination.
5. Click **OK** to save the adding.
6. (Optional) After adding the multi-door interlocking combination, you can select it from the list and click **Delete** to delete the combination.
7. Click **Save** button to save and take effect.

7.7.8 Authentication Password

Purpose:

You can open the door by inputting the authentication password (PIN) on the card reader keypad. This PIN / Password is different to that entered in the Card Holder profile for the Card and Code option.


Notes:

- This authentication password function is only valid during the schedules when the card reader authentication mode for the access control device is set as **Card or Authentication Password**. For details, please refer to *Chapter 7.7.2 Card Reader Authentication*.
- This function should be supported by the access control device.



Steps:

1. Click **Authentication Password** tab and select an access control device from the list.



Once the controller is selected, all the cards and persons which have been applied to the device will be displayed.

Note:

- It is important to click on the controller each time you enter the “Authentication Password” field to refresh the list of card applied to that controller.
- For setting and applying the permissions to the device, refer to *Chapter 7.6 Permission Configuration*.

2. Click the **Password** field of the card and input the authentication password for the card.

Note: The authentication password should contain 4 to 8 digits.

3. After setting the authentication password, the authentication password function of the card will be enabled.

4. (Optional) You can input the keywords of card No., person name, or authentication password to search from the Filter Field in the top right of the screen.

Notes:

- Up to 500 cards with authentication password can be added to one access control device.
- The password should be unique and cannot be the same with super password, duress code, and dismiss code in the access control parameters.

7.7.9 Custom Wiegand

Do not attempt to touch these settings unless you have a clear understanding of 3rd party integration.

Purpose:


Based on the knowledge of uploading rule for the third party wiegand, you can set multiple customized wiegand protocols to communicate between the controller and the third party card readers.

Before you start:


Wire the third party card readers to the controller.

Steps:





1. Click **Custom Wiegand** to enter the Custom Wiegand tab.



2. Select a custom wiegand on the left of the interface.
3. Check **Enable** checkbox to enable the custom wiegand.
4. Set the wiegand name.
5. Select device.
 - 1) Click **Select Device**.
 - 2) Select the device need to use custom wiegand.
 - 3) Click **OK** to save the settings.
6. Input the Total Length and select the parity mode in the drop-down list.
 If you select Odd-Even Parity, you should set the odd parity start bit, the odd parity length, the even parity start bit and the even parity length.
 If you select XOR Parity, you should set the XOR parity start bit, length per group and total length.
 If you select None, you are no need to set the parity mode.
7. Set output transformation rule.
 - 1) Click **Set Rule** to pop up the Set Output Transformation Rules window.




- 2) Select rules on the left list.
Note: Press the *Shift* key to select multiple rules.

- 3) Click  to move the selected rules to the right list.
 - 4) (Optional) Click  or  to change the rule order.
 - 5) (Optional) Select the rules in the Selected Rule list and click  to remove the rule from the list on the right.
 - 6) Click **OK** to save the settings.
 - 7) In the Custom Wiegand tab, set the rule start bit, length, and the decimal digit.
8. Click **Save** at the upper right corner of the interface to save the settings.

Notes:


- By default, the device disables the custom wiegand function.
- If the device enables the custom wiegand function, all wiegand interfaces in the device will use the customized wiegand protocol.
- Up to 5 custom wiegands can be set.
- Up to 32 characters are allowed in the custom wiegand name.
- Up to 80 bits are available in the total length.
- The odd parity start bit, the odd parity length, the even parity start bit and the even parity length range from 1 to 80 bit.
- The start bit of the card ID, the manufacturer code, the site code, and the OEM should range from 1 to 80 bit.
- For details about the custom wiegand, see Appendix.





7.8 Searching Access Control Event

Purpose:

You can search the access control history events including device exception event, door event, alarm input, and card reader event.

Click  icon and click Access Control Event tab to enter the following interface.



Steps:


1. Select the source.
You can select Client or Device.
2. Enter the search condition (source, event type/card holder name/card No./capture/start & end time).
3. Click **Search** to get the search results.
4. View the event information in the event list.
5. Click an event to view the information of the card holder on the **Card Holder Information** panel on the left side of the page.
6. You can click **Export** button to export the search results to the local PC.

7.9 Access Control Event Configuration

Purpose:

For the added access control device, you can configure its access control linkage including access control event linkage, access control alarm input linkage, event card linkage, and cross-device linkage.

Click the  icon on the control panel, or click **Tool->Event Management** to open the Event Management page.



7.9.1 Access Control Event Linkage


Purpose:

You can assign linkage actions to the access control event by setting up a rule. For example, when the access control event is detected, an audible warning appears or other linkage actions happen.

Note: The linkage here refers to the linkage of the client software's (iVMS4200) actions.

Steps:

1. Click the **Access Control Event** tab.



2. The added access control devices will display in the Access Control Device panel on the left. Select the access control device, or alarm input, or access control point (door), or card reader to configure the event linkage.
3. Select the event type to set the linkage. (e.g. Access Granted (Normal Card Authenticated Passed), Invalid card etc)
4. Select the triggered camera. The image or video from the triggered camera will pop up when the selected event occurs.
To capture the picture / record the event of the triggered camera when the selected event occurs, you must first program and setup a schedule and the storage in 'Storage Schedule'.
5. Check the checkboxes to activate the linkage actions. For details, refer to *Table 14.1 Linkage Actions for Access Control Event*.

6. Click **Save** to save the settings.
7. You can click Copy to button to copy the access control event to other access control device, alarm input, access control point, or card reader.
Select the parameters for copy, select the target to copy to, and click **OK** to confirm.




Table 1. 1 Linkage Actions for Access Control Event

Linkage Actions	Descriptions
Audible Warning	The client software gives an audible warning when alarm is triggered. You can select the alarm sound for audible warning.
Email Linkage	Send an email notification of the alarm information to one or more email recipients.
Alarm on E-map	Display the alarm information on the E-map. Note: This linkage is only available to access control point and alarm input. (i.e. Events)
Alarm Triggered Pop-up Image	The image with alarm information pops up when alarm is triggered.

7.9.2 Access Control Alarm Input Linkage


Purpose:

The access control alarm inputs can be linked to some actions (e.g., alarm output, host (controllers) buzzer etc) when it is triggered.

Note: The linkage here refers to the linkage of the client software's (iVMS4200) own actions.

Steps:

1. Click **Access Control Alarm Input** tab to enter the following interface.




2. In the event list on the left, select an alarm / Event input.
3. Switch the property from to to enable this action.
 - Host Buzzer:** The audible warning of controller will be triggered.
 - Card Reader Buzzer:** The audible warning of card reader will be triggered.
 - Alarm Output:** The alarm output will be triggered for notification.
 - Access Control Point (Open/Close):** The door will be open or closed when the event is triggered.
- Note:** The Door cannot be configured as open or closed at the same time. They need to be different Events. E.g. Event 1 may open / unlock and door and Event 2 may close / lock the door.
4. Click **Save** button to save the settings.

7.9.3 Event Card Linkage

Click **Event Card Linkage** tab to enter the following interface.

Notes:

- The Event Card Linkage should be supported by the device.
- The linkage here refers to the linkage of the iVMS4200 client software's own actions.



Select the access control device from the list on the left.

Click **Add** button to add a new linkage. You can select the event source as **Event Linkage** or **Card Linkage**.

Event Linkage

For the event linkage, the alarm event can be divided into four types: device event, alarm input, door event, and card reader event.

Steps:

1. Click to select the linkage type as **Event Linkage**, and select the event type from the dropdown list.
 - For Device Event, select the detailed event type from the dropdown list.
 - For Alarm Input, select the type as alarm or alarm recovery and select the alarm input name from the table.
 - For Door Event, select the detailed event type and select the source door from the table.
 - For Card Reader Event, select the detailed event type and select the card reader from the table.
2. Set the linkage target, and switch the property from to to enable this function.
 - **Host Buzzer:** The audible warning of controller will be enabled/disabled.
 - **Capture:** The real-time capture will be enabled.

- **Card Reader Buzzer:** The audible warning of card reader will be enabled/disabled.
- **Alarm Output:** The alarm output will be enabled/disabled for notification.
- **Zone:** Arm or disarm the zone.
- **Access Control Point:** The door status of open, close, remain open, and remain closed will be enabled.



Notes:

- The door status of open, close, remain open, and remain close cannot be triggered at the same time.
- The target door and the source door cannot be the same one.


3. Click **Save** button to save and take effect of the parameters.

Card Linkage

Steps:

1. Click to select the linkage type as **Card Linkage**.
2. Input the card No. or select the card from the dropdown list.
3. Select the card reader from the table for triggering.
4. Set the linkage target, and switch the property from  to  to enable this function.
 - **Host Buzzer:** The audible warning of controller will be enabled/disabled.
 - **Capture:** The real-time capture will be enabled.
 - **Card Reader Buzzer:** The audible warning of card reader will be enabled/disabled.
 - **Alarm Output:** The alarm output will be enabled/disabled for notification.
 - **Zone:** Arm or disarm the zone.
 - **Access Control Point:** The door status of open, close, remain open, and remain closed will be enabled.
5. Click **Save** button to save and take effect of the parameters.

Note: When you program a Card Linkage event whereby it is assigned to an Alarm O/P then 1 card swipe will activate the O/P. There is also a 'special' application applied to these Card Linkage events, in that 3 Card swipes of the same card (as programmed in the event linkage) within 5 seconds will deactivate the O/P. This could be used for Arming and Disarming an alarm panel such as the Ness M1 Controller or Ness D8X panels.




7.9.4 Cross-Device Linkage

Purpose:

You can assign to trigger other access control device’s action by setting up a rule when the access control event is triggered.

Click **Cross-Device Linkage** tab to enter the following interface.



Click **Add** button to add a new client linkage. You can select the event source as **Event Linkage** or **Card Linkage**.

Event Linkage

For the event linkage, the alarm event can be divided into four types: device event, alarm input, door event, and card reader event.

Steps:

1. Click to select the linkage type as **Event Linkage**, select the access control device as event source, and select the event type from the dropdown list.
 - For Device Event, select the detailed event type from the dropdown list.
 - For Alarm Input, select the type as alarm or alarm recovery and select the alarm input name from the table.
 - For Door Event, select the detailed event type and select the door from the table.
 - For Card Reader Event, select the detailed event type and select the card reader from the table.
2. Set the linkage target, select the access control device from the dropdown list as the linkage target, and switch the property from to to enable this function.
 - **Alarm Output:** The alarm output will be triggered for notification.
 - **Access Control Point:** The door status of open, close, remain open, and remain close will be triggered. **Note:** The door status of open, close, remain open, and remain close cannot be triggered at the same time.

3. Click **Save** button to save parameters.



Card Linkage

Steps:

1. Click to select the linkage type as **Card Linkage**.
2. Select the card from the dropdown list and select the access control device as event source.
3. Select the card reader from the table for triggering.
4. Set the linkage target, select the access control device from the dropdown list as the linkage target, and switch the property from to to enable this function.

Alarm Output: The alarm output will be triggered for notification.

5. Click **Save** button to save parameters.

7.10 Door Status Management

Note:


- Before use, see section 7.11.1 Access Control Group Management below.

Purpose:


The door status of the added access control device will be displayed in real time. You can check the door status and the linked event(s) of the selected door. You can control the status of the door and set the status duration of the doors as well.

From the 'Control Panel' select  to open 'Status Monitoring'


Select the 'Door Status' tab to open the 'Door Status Management' feature.
From the left hand window select the controller / Door Group you wish to monitor.



Select the “Card Swiping Record” to view live Card Swiping events as they come in.



(Note – When first opening the above screen, previous events may not be visible and only new events will come through as they occur. For past events use the Access Control / Search feature.




7.10.1 Access Control Group Management



Purpose:


Before controlling the door status and setting the status duration, you are required to organize it into group for convenient management.

Perform the following steps to create the group for the access control device:

Steps:

1. Click  on the control panel to open the Device Management page.
2. Click **Group** tab to enter the Group Management interface.



3. Perform the following steps to add the group.
 - 1) Click  to open the 'Add' Group dialog box.
 - 2) Enter a group name as you want. (e.g. All Access Doors)
 - 3) Click **OK** to add the new group to the group list.
 You can also check the checkbox **Create Group by Device Name** to create the new group by the name of the selected device.





4. Perform the following steps to import the access control points to the group:

- 1) Click **Import** on Group Management interface, and then click the **Access Control** tab to open the Import Access Control page.

Notes:

- You can also select **Alarm Input** tab and import the alarm inputs to group.
 - For the Video Access Control Terminal, you can add the cameras as encoding channel to the group.
- 2) Select the names of the access control points in the list.
 - 3) Select a group from the group list.
 - 4) Click **Import** to import the selected access control points to the group.
You can also click **Import All** to import all the access control points to a selected group.




5. After importing the access control points to the group, you can click , or double-click the group/access control point name to modify it.


7.10.2 Anti-control the Access Control Point (Door)

Purpose:

You can control the status for a single access control point (a door), including opening door, closing door, remaining open, and remaining closed.



Click  icon on the control panel to enter the Status Monitor interface.




Steps:

1. Select an access control group on the left. For managing the access control group, refer to *Chapter 0 Purpose*:
2. *The door* status of the added access control device will be displayed in real time. You can check the door status and the linked event(s) of the selected door. You can control the status of the door and set the status duration of the doors as well.

From the 'Control Panel' select  to open 'Status Monitoring'


Select the 'Door Status' tab to open the 'Door Status Management' feature.
From the left hand window select the controller / Door Group you wish to monitor.



Select the “Card Swiping Record” to view live Card Swiping events as they come in.


Card No.	Person Name	Organization	Event Time	Door Position	Direction	Authentication Result	Operation
03809399	Greg Kingsley	Ness	2018-03-26 15:29:56	Main Office - 4 Door Controller:Entrance Card Reader1	Enter	Legal Card Authentication Passed	
03809399	Greg Kingsley	Ness	2018-03-26 14:29:58	DS-K2604 (L):Entrance Card Reader5	Enter	Legal Card Authentication Passed	
14511850	14511850	Ness	2018-03-26 14:29:56	DS-K2604 (L):Entrance Card Reader1	Enter	Invalid Card	
03809237	Malcolm Turnbull	Ness	2018-03-26 15:29:48	Main Office - 4 Door Controller:Entrance Card Reader5	Enter	Permission Mismatch	
03809237	Malcolm Turnbull	Ness	2018-03-26 15:29:42	Main Office - 4 Door Controller:Entrance Card Reader1	Enter	Legal Card Authentication Passed	
20943500			2018-03-26 15:29:38	Main Office - 4 Door Controller:Entrance Card Reader1	Enter	Invalid Card	
03809237	Malcolm Turnbull	Ness	2018-03-26 14:29:39	DS-K2604 (L):Entrance Card Reader3	Enter	Legal Card Authentication Passed	
03809399	Greg Kingsley	Ness	2018-03-26 14:29:36	DS-K2604 (L):Entrance Card Reader1	Enter	Legal Card Authentication Passed	

(Note – When first opening the above screen, previous events may not be visible and only new events will come through as they occur. For past events use the Access Control / Search feature.



3. Access Control Group Management.

4. The access control points of the selected access control group will be displayed on the right.



Click icon on the Status Information panel to select a door.

5. Click the following button listed on the **Status Information** panel to control the door.

- Open Door** : Click to open the door once.
- Close Door** : Click to close the door once.
- Remain Open** : Click to keep the door open.
- Remain Closed** : Click to keep the door closed.
- Capture** : Click to capture the picture manually.


6. You can view the anti-control operation result in the Operation Log panel.

Notes:

- If you select the status as **Remain Open/Remain Closed**, the door will keep open/closed until a new anti-control command being made.
- The **Capture** button is available when the device supports capture function. And it cannot be realized until the storage server is configured.
- If the door is in remain closed status, only super card can open the door or open door via the client software.

7.10.3 Real-time Card Swiping Record

Click **Card Swiping Record** tab to enter the following interface.



The logs of card swiping records of all access control devices will display in real time. You can view the details of the card swiping event, including card No., person name, organization, event time, etc.

You can also click the event to view the card holder details, including person No., person name, organization, phone, contact address, etc.

7.10.4 Real-time Access Control Alarm

Purpose:


The logs of access control events will be displayed in real time, including device exception, door event, card reader event, and alarm input.

Click **Access Control Alarm** tab to enter the following interface.

Subscribe				
Alarm Type	Alarm Time	Alarm Location	Alarm Content	Operation
Remote: Disarm...	2016-12-16 13:5...	Access Controller	Remote: Disarm...	
Remote: Arming	2016-12-16 13:5...	Access Controller	Remote: Arming	
Remote: Login	2016-12-16 13:5...	Access Controller	Remote: Login	
Remote: Disarm...	2016-12-16 13:5...	Access Controller	Remote: Disarm...	
Remote: Logout	2016-12-16 13:5...	Access Controller	Remote: Logout	
Remote: Login	2016-12-16 13:5...	Access Controller	Remote: Login	
Remote: Arming	2016-12-16 13:4...	Access Controller	Remote: Arming	
Remote: Login	2016-12-16 13:4...	Access Controller	Remote: Login	
Remote: Disarm...	2016-12-16 13:4...	Access Controller	Remote: Disarm...	
Door Locked	2016-12-16 13:4...	Door1	Door Locked	
Unlock	2016-12-16 13:4...	Door1	Unlock	
Remote: Arming	2016-12-16 13:4...	Access Controller	Remote: Arming	
Remote: Login	2016-12-16 13:4...	Access Controller	Remote: Login	
Remote: Disarm...	2016-12-16 13:4...	Access Controller	Remote: Disarm...	

Steps:

1. All access control alarms will display in the list in real time. You can view the alarm type, alarm time, location, etc.
 2. Click to view the alarm on E-map.
 3. You can click or to view the live view or the captured picture of the triggered camera when the alarm is triggered.
- Note:** For setting the triggered camera, refer to *Chapter 7.9.1 Access Control Event Linkage*.
4. Click **Subscribe** to select the alarm that the client can receive when the alarm is triggered.



- 1) Check the checkbox(es) to select the alarm(s), including device exception alarm, door event alarm, card reader alarm, and alarm input.
- 2) Click **OK** to save the settings.

3)


7.11 Arming Control

Purpose:

You can arm or disarm the device. After arming the device , the client can receive the alarm information from the device.

Steps:

1. Click **Tool->Device Arming Control** to pop up the Device Arming Control window.
2. Arm the device by checking the corresponding checkbox.
Then the alarm information will be auto uploaded to the client software when alarm occurs.



C O R P O R A T I O N

Appendix A Sound Prompt and Indicator

After the card reader is powered on, LED status indicator will turn blue and blink for 1 time. Then it will turn red and blink for 3 times. At last the buzzer will send out a beep sound indicating the starting up process is completed.

During using the card reader, it will send out different sounds prompt and the LED indicator on it have different statuses. You can refer to tables below for detailed information.

Table 7-1 Description of Prompt Sound

Sound Prompt	Description
One beep	RS-485 protocol: Pressing keys prompt; Swiping card prompt; Time out prompt for pressing keys or swiping card. Wiegand protocol: Pressing keys prompt; Swiping card prompt.
Two rapid beeps	The operation of pressing keys or swiping card is valid.
Three slow beeps	The operation of pressing keys or swiping card is invalid.
Rapidly continuous beeps	Alarm of tamper-proof.
Slowly continuous beeps	The card reader is unencrypted.

Table 7-2 Description of LED Indicator

LED Indicator Status	Description
Green and blinking	Card reader is working normally.
Solid green	The operation of pressing keys or swiping card is valid.
Solid red	The operation of pressing keys or swiping card is invalid.
Red and blinking	For RS-485 protocol: Registering failed or card reader is offline. Failed to get key files of PSAM card; Failed to detect the PSAM card.
Red and Keeping rapidly blinking	Available for reading file mode of CPU card: PSAM is not inserted or undetected.

Appendix B Custom Wiegand Rule Descriptions

Take Wiegand 44 as an example, the setting values in the Custom Wiegand tab are as follows:

Custom Wiegand Name:	Wiegand 44				
Total Length	44				
Transformation Rule (Decimal Digit)	byFormatRule[4]=[1][4][0][0]				
Parity Mode	XOR Parity				
Odd Parity Start Bit		Length			
Even Parity Start Bit		Length			
XOR Parity Start Bit	0	Length per Group	4	Total Length	40
Card ID Start Bit	0	Length	32	Decimal Digit	10
Site Code Start Bit		Length		Decimal Digit	
OEM Start Bit		Length		Decimal Digit	
Manufacturer Code Start Bit	32	Length	8	Decimal Digit	3

Wiegand Data = Valid Data + Parity Data

Total Length: Wiegand data length.

Transportation Rule: 4 bytes. Display the combination types of valid data. The example displays the combination of Card ID and Manufacturer Code. The valid data can be single rule, or combination of multiple rules.

Parity Mode: Valid parity for wiegand data. You can select either odd parity or even parity.

Odd Parity Start Bit, and Length: If you select Odd Parity, these items are available. If the odd parity start bit is 1, and the length is 12, then the system will start odd parity calculation from bit 1. It will calculate 12 bits. The result will be in bit 0. (Bit 0 is the first bit.)

Even Parity Start Bit, and Length: If you select Even Parity, these items are available. If the even parity start bit is 12, and the length is 12, then the system will start even parity calculation from bit 12. It will calculate 12 bits. The result will be in the last bit.

XOR Parity Start Bit, Length per Group, and Total Length: If you select XOR Parity, these items are available. Depending on the table displayed above, the start bit is 0, the length per group is 4, and the total length is 40. It means that the system will calculate from bit 0, calculate every 4 bit, and calculate 40 bits in total (10 groups in total). The result will be in the last 4 bits. (The result length is the same as the length per group.)

Card ID Start Bit, Length, and Decimal Digit: If you use the transformation rule, these items are available. Depending on the table displayed above, the card ID start bit is 0, the length is 32, and the decimal digit is 10. It represents that from bit 0, there are 32 bits represent the card ID. (The length here is calculated by bit.) And the decimal digit length is 10 bits.

Site Code Start Bit, Length, and Decimal Digit: If you use the transformation rule, these items are available. For detailed information, see the explanation of the card ID.

OEM Start Bit, Length, and Decimal Digit: If you use the transformation rule, these items are available. For detailed information, see the explanation of the card ID.

Manufacturer Code Start Bit, Length, and Decimal Digit: If you use the transformation rule, these items are

available. Depending on the table displayed above, the manufacturer code start bit is 32, length is 8, and decimal digit is 3. It represents that from bit 32, there are 8 bits are manufacturer code. (The length here is calculated by bit.) And the decimal length is 3.

0200001071120





First Choice for Security Professionals

This manual has been modified by Ness Corporation for our valued customers.



www.nesscorporation.com

www.hikvision.com